

NEPTUN ZATURN JUPITER



Original

Instruction book

67025102-100 - Version 1.00

GB - 09.2015



www.hardi.es

www.hardi-international.com



Congratulations for choosing a HARDI crop protection product. The reliability and efficiency of this machine depends entirely on the care it receives. The first step is to carefully read and pay attention to this instruction book. It contains essential information on correctly using and ensuring a long useful life of this quality product.

As this instruction book includes all versions of the equipment, including all the different hydraulic boom and operating unit versions, please pay particular attention to the paragraphs dealing with your specific model.

This book should be read in conjunction with the 'Spraying Techniques' booklet

The original instruction book is approved and published in English. All other languages are translations of the original. In the event of any conflicts, inaccuracies or deviations between the English original and other languages the English version shall prevail.

Since it is ILEMO-HARDI S.A.U. policy to continually improve our products, we reserve the right to make changes in the design, accessories, specifications and maintenance instructions at any time and without notice.

ILEMO-HARDI S.A.U. is exempt from any obligation regarding instruments purchased before or after such changes. ILEMO-HARDI S.A.U. cannot undertake any responsibility for possible omissions or inaccuracies in this publication, although it has done everything in its power to make this information as complete and correct as possible.

As this instruction book covers models, specifications or equipment that are only available in certain countries, please pay particular attention to the paragraphs dealing with your specific model.

Published and printed by ILEMO-HARDI S.A.U.

Table of Contents

1 - EC Declaration	
EC Declaration of Conformity	5
2 - Safety	
Operator safety	7
Symbols.....	7
Precautions.....	7
3 - Description	
General information	9
Overview	9
Use of the mist blower.....	11
Roadworthiness	11
Identification plate	11
Chassis.....	11
Tank.....	12
Liquid system	13
General information	13
The liquid circuit	13
Diaphragm pump.....	13
Valves	13
Valves and symbols.....	13
Manifold system.....	14
Blue valve – Blue disc = Return valve	14
Circuit Diagram.....	15
Suction filter	15
Safety valve.....	16
Pressure manifold.....	16
Suction and pressure pulsation dampers	16
Agitator.....	16
Operating unit.....	17
MC/2 operating unit.....	17
SV operating unit.....	17
CB operating unit.....	17
Filters	17
Powder mixer.....	17
TurboFiller	18
Axial blower units	19
Technical information.....	19
EF820, EF920, AB750, AB820, AB920, AG820, AG920, IAG820, IAG920, SF65, SF85 and XF90.....	19
Air flow for axial air kits.....	21
Deflectors.....	22
Gearbox.....	23
Fan	23
Specific for SF and XF axial fans	23
Centrifugal Blower Units	24
General information	24
HF540 (TS3 P540 / TS6 P540 Single).....	24
HF540D (TD3-P540 Double)	24
HF640D (TD3-P640 Double)	24
Protective grid.....	25
Gearbox.....	26
HF540, HF540D and HF 640D Turbine.....	26
Clutch (All blower types)	26
Equipment	27
Ring drawbar.....	27
Fork drawbar	27
Turnable drawbar	27
Wedges.....	28
Light kit.....	28
Booms.....	28
The LINER boom	28

Table of Contents

The ATLAS boom	29
The BOXER boom	30
The CRONOS boom	31
Break away clutch	32
Particularly for CRONOS boom	32
Pneumatic spray system	33
Hydropneumatic spray system	33
IRIS system, continuation of Hydro pneumatic system	34

4 - Starting up

General information.....	35
Unloading the mistblower from the truck	35
Before starting up for the first time.....	35
Counterweights	35
Mechanical connections	36
Adjusting the drawbar length.....	36
Jockey wheel.....	36
Connecting the fork drawbar	36
Connecting the ring drawbar.....	36
Connecting the articulated drawbars	37
Lock device on turnable drawbar	37
Coupling the driveshaft.....	38
Hydraulic connections.....	39
General information	39
Tractor requirements.....	39
Electrical connections	40
General information	40
CB/2 operating unit	40
Rate controller.....	41
Rate controller DB 3610.....	41
Rate controller DB 3620.....	42
Fluid circuit	43
Suction filter	43
Pressure damper	43
Diaphragm pump	43
Deflectors	44
Booms	47
General information	47
FIX	47
START	47
ATLAS START	48
ATLAS AGILE.....	48
ATLAS SOLID FIX and ATLAS SOLID FIX GV.....	48
ATLAS SOLID CONVERT and ATLAS SOLID GV CONVERT	48
BOXER START.....	49
BOXER SOLID VERTICAL FIX or CONVERT	49
BOXER SOLID HORIZONTAL	49
Adjustment of BOXER boom.....	50
CRONOS BOOM.....	50
SOLID	50
RIDER.....	51
VARIA	51
CRONOS GV	51
General for all boom models	52
Break away clutch	52
Adjustment of hydraulic fold	52
Transport bracket	53
Adjustment of upright	53
Adjustment of out spray device.....	53
The hydraulic version.....	54
Adjustment of inner 4 spray device.....	54
Hydraulic adjustment of the Convert brackets	55

Table of Contents

IRIS system setup.....	55
Cannons.....	56
Calibration.....	56
5 - Operation	
Blower unit.....	57
Safety information.....	57
Selecting the gear.....	57
While moving the Sprayer.....	58
Adjusting the fan A6820 and SF65/SF85 and XF90.....	59
Single side blinds (Optional).....	59
Fluid circuit.....	60
Filling/washing location requirements.....	60
Filling with water.....	60
Filling through tank lid.....	61
Filling the rinsing tank.....	61
Rinsing nozzle.....	61
Filling the clean water tank.....	62
Drain valve.....	62
Manifold system.....	62
Filling liquid chemicals by HARDI TurboFiller (optional).....	63
TurboFiller rinsing.....	64
Power supply.....	65
Installation of control unit brackets.....	65
SB 3002 or SB 3004.....	66
SV operating unit.....	66
SB 3012 or SB 3014 etc.....	66
SB 3012 or SB 3014 etc.....	67
FB 3610.....	67
CB operating unit.....	67
CB operating unit with by pass valve.....	67
Hydraulic control boxes.....	68
HB 3610.....	68
The Joystick S selector.....	68
Cannon L-M-T.....	69
Hydraulic control of the CANNON.....	69
The hydraulic adjustment.....	69
HC 3100 control box.....	70
Vegetation sensor is optionally equipped.....	70
HC 3150.....	71
HC 3150.....	73
HJ 3200 Joystick & HC3050.....	75
Work menu.....	76
Rate controller DB3610 and DB3620.....	77
Adjusting the BK/2 Operating Unit.....	79
MC/2 operating unit.....	79
Cleaning.....	80
General information.....	80
Cleaning and maintaining the filters.....	80
Cleaning the tank and liquid system.....	81
Use of rinsing tank and rinsing nozzles (optional).....	81
6 - Maintenance	
Lubrication.....	84
General information.....	84
Recommended lubricants.....	84
Lubricating and greasing the mistblower.....	84
Transmission shaft.....	86
Tank transmission shaft.....	86
Diaphragm pump.....	86
Filters and fittings.....	87
Fork drawbar.....	87

Table of Contents

Ring drawbar.....	87
Articulated drawbar.....	88
Axles with brake.....	88
Service and maintenance intervals	89
General information	89
Every 10 working hours – Spray circuit	89
Every 50 working hours – Transmission shaft, chassis, air pressure and diaphragm pump	89
Every 100 working hours – Drawbar.....	89
Every 250 working hours – Wheels, brakes, hoses and gearbox.....	89
Every 1000 working hours – Full service.....	89
Regular maintenance	90
Every 10 working hours – Suction filter	90
Every 10 hours of operation – Pressure filters	90
Every 10 working hours – Nozzles.....	91
Every 1000 working hours - Gearbox oil change	91
Every 1000 working hours - Fan clutch inspection.....	92
Every 1000 working hours - Fan transmission shaft inspection.....	92
Occasional maintenance	93
Replacing the 321 valves and diaphragms	93
SV operating unit.....	93
CB Section valve.....	94
Cleaning the air kit	96
Tank level indicator adjustment.....	97
Replacing the valves and 363 and 463 diaphragms	97
Lubrication	98
General information	98
Grease Gun Calibration.....	99
Greasing the Pump	99
Service and Maintenance Intervals	100
50 Hours Service - Greasing the Pump.....	100
Occasional Maintenance	101
Lifting and Removing the Pump	101
Pump Valves and Diaphragms Renewal	101
Adjusting the 3-way valve	103
Replacing the driveshaft protector guard	103
Replacing the driveshaft crossheads	103
Annual maintenance of tank PTO	104
Replacing the seal on the drain valve.....	105
Storing the mistblower at the end of the season.....	105
Preparing the machine for use after storage	106
7 - Troubleshooting	
Operational problems	107
General information	107
Fluid circuit.....	108
Blower unit.....	109
Electrical problems	110
Emergency function – Fluid circuit.....	110
8 - Technical specifications	
Axial dimensions and weight	111
Turbines dimensions and weight	114
Conversion factors (SI to Imperial).....	116
Specifications	117
Pump model 363/7	117
Pump model 321/10	117
Filters and nozzles.....	117
Temperature and pressure range.....	117
Materials and recycling	118
Disposing of the mistblower.....	118

Index

EC Declaration of Conformity



Manufacturer:
ILEMO HARDI S.A.U.
Poligono El Segre, 712, 713
25080 Lleida
SPAIN

Declares the following product(s):

NEPTUN

ZATURN

JUPITER

- hare manufactured in conformity with the applicable provisions of the Directive 2006/42/EC on machinery, and
- all the applicable provisions of the Council Directive 2004/108/EC (EMC)

Lleida, March 2015

A handwritten signature in black ink, appearing to read 'Josep M. Godia', written in a cursive style.

Josep Maria Godia
Technical Director
ILEMO HARDI S.A.U.

Operator safety

Symbols

These symbols are used in the book and require special attention. The meaning of the four symbols is:



This symbol means DANGER. Be alert as your safety is involved!



This symbol means WARNING. Be alert as your safety may be involved!



This symbol means ATTENTION. This will guide you on how to correctly and safely use the sprayer equipment.



This symbol means NOTE.

Precautions

Please note these precautions and safe operating practices before using the sprayer.

General information



Read and fully understand this instruction book before using the equipment. It is also equally important that other operators of the equipment read and understand this book.

If you do not fully understand any part of this instruction book after reading it, please contact your HARDI distributor for further information before using the equipment.



Local law may demand the operator to be certified to use this spray equipment. Comply with the law.



The tractor seat is the safest area when handling the equipment.



Wear protective clothing. Protective clothing may vary according to the chemical product being used. Comply with regulations.

Wash and change clothes after spraying. Clean the tools if they have become contaminated.



Do not eat, drink or smoke while spraying or working with contaminated equipment.

In the event of poisoning, immediately seek medical advice. Remember to identify the chemicals used.

Filling and spraying



Be careful not to hit persons or objects while manoeuvring the spraying equipment, especially when reversing.



Slow down when driving over uneven terrain as the machine could overturn.



Keep children away from the sprayer.



Do not attempt to enter the tank.



Do not climb over the sprayer unless it has been securely fastened. The boom is only secure when it is placed in the transport brackets.

2 - Safety

Service



Always pressure test with clean water before filling with chemicals. Do not remove the hose if the machine is turned on.

DANGER! Do not exceed the maximum recommended r.p.m.



Rinse and wash out the equipment after use and before servicing.



Do not remove the hose if the machine is turned on. Always replace all safety devices or shields immediately after servicing.



Disconnect the power supply before servicing, and de-pressurise the equipment after use and servicing.



If an arc welder is used on the equipment, disconnect any power leads before welding.




Remove all inflammable or explosive materials from the area.



The External Cleaning Device should not be used if any part of the equipment has been damaged, including safety devices, high-pressure hoses, etc.


General information

Overview



- | | |
|---|--------------------------|
| 1. Main tank | 7. Clean water tank |
| 2. Level indicator, optionally on top of the tank | 8. Main lid and strainer |
| 3. Manifold valves | 9. TurboFiller |
| 4. Suction filter | 10. Drawbar |
| 5. Pump | 11. Operating unit |
| 6. Rinsing tank | |

3 - Description



- 12. Chassis
- 13. Fan house
- 14. Grid and air guide
- 15. Centre cover
- 16. Bumper and light bar

- 17. Gear box filling point
- 18. Air outlet
- 19. Spray line
- 20. Adjustable bottom deflector
- 21. Operating unit and hydraulic valves

3 - Description

Use of the mist blower

The HARDI mist blower is designed for applying chemical products used for crop protection. This equipment may only be used for this purpose. The use of this equipment for other purposes is not allowed. If there is no special law in your region which obliges the user to have a permit, it is recommended to be well-prepared for protecting crops in a correct way and for handling chemical products safely so as to avoid unnecessary risks to people and the environment while spraying takes place.

For environmental issues the air kit is offered with option to close either left or right side of the air stream from the blower. These blinds, are mandatory in some sensitive areas, to avoid chemical contaminated air, blowing towards river sides and water channels

Roadworthiness

When driving on public roads and other places where the road safety code or where there are other special rules and regulations for marking and lights on machinery, the machine must be equipped to comply with these regulations.



ATTENTION! For models not fitted with brakes the maximum speed is 25 km/h and 40 km/h for those with. This could vary according to local legislation. Contact your local authorities to find out the current maximum speed limits.

Identification plate

The identification plate is located on the front right-hand side of the machine and is riveted to the chassis. It indicates the make, model, serial number, and date of manufacture.



The serial number is also engraved onto the chassis. The number is found above the identification plate, as indicated in the picture. The serial number consist of five digits.



Chassis

The monoblock cold-pressed metal chassis is highly durable and built to last under everyday use under extreme conditions. It is manufactured using only the most advanced laser cutting and automated soldering processes. To protect against corrosion it is coated with a polyurethane bi-component paint on top of a highly adherent, steel blasted base.

3 - Description

Tank

The main tank made of impact-proof, UV-resistant and chemical resistant polyethylene, has a purposeful design with no sharp corners for easy cleaning. Nominal contents are 1000, 1500, 2000 or 3000 l. A large, easy to read tank contents indicator is placed on the front - right-hand side and another one is placed on the left side. First one is visible from the tractor cabin. The filling hole is accessible from the left-hand side. This ensures an easy access for the filling of spray liquid, cleaning of the tank, etc. The mistblower is equipped with a clean water tank integrated with the main tank design.

Liquid system

General information

All the suction system functions are operated via a 3-way valve. The pressure valve is also to be found in the pressure circuit. The low pressure circuit is called HLC (Hardi Liquid Circuit).

The liquid circuit

Consists of a manifold system in the working zone (front part) where pressure manifold receives liquid from the pump, and distributes to the different options on the sprayer: to the operating unit, to the TurboFiller, to the bottle cleaner, to the Powder mixer in strainer etc., all according to configuration of options. The suction manifold in same area allows suction from main tank, rinsing tank or external water source, if fitted, depending on the configuration.

The pressure side of the liquid circuit is fitted with a safety valve to protect the circuit against misuse of excessive pressure. See chapter "Safety valve"

Diaphragm pump


Pumps with a diaphragm: Models 321/10 (max. 20 bar) or 363/7 (max. 20 bar)

They are low pressure and robustly built. Use only grease for lubrication. The 363 model has six diaphragms and the 321 has two. This type of pump is self-priming, works without oil and can run dry as long as necessary.

Valves

The suction valve is located above the pump and is used to select where to suck liquid from. Either suction from the main tank for spraying or from the rinse tank for internal cleaning of the liquid circuit. The function is selected by turning the handle of the valve towards the desired function.

 ATTENTION! If one of the handles is too tight - or too loose (= liquid loss) - the valve needs to be serviced. For more information, see section on "Maintenance".



Valves and symbols

The valves are identified by coloured discs fitted on the valves themselves. The symbols correspond to the optional accessories, and are located on the discs for quick identification and handling. To activate/open a function, turn the lever to the desired function.

 ATTENTION: Only the functions to be used should be activated – the other valves should always be kept closed.


 ATTENTION: If the handle of a MANIFOLD valve is too tight – or too loose (loss of fluid)– the valve needs to be serviced. For more information, see the section on 'Maintenance'.

3 - Description

Manifold system

The functions of the spray circuit are operated via the centrally situated MANIFOLD with colour coded plates and pictorial symbols for easy operation.


The modular valve system facilitates the addition of optional extras on both pressure (A) and suction (B) for agitation and for rinsing nozzle (optional equipment).



Blue valve – Blue disc = Return valve




Towards agitation




Towards the suction pump

The position of the return MANIFOLD valve determines where the excess flow from the fluid circuit goes. When the arrow on the handle points to a symbol, the excess fluid will be fully sent towards that function (the example shows agitation). This valve does not have the '0' position.



3 - Description


Circuit Diagram



- | | |
|--|-------------------------------|
| 1. Main tank | 8. Manifold valves |
| 2. Rinsing tank | 9. TurboFiller |
| 3. Powder mixer or bottle cleaner (optionally) | 10. Rinsing nozzles |
| 4. Pump | 11. Ventury agitation nozzles |
| 5. Suction filter | 12. Operating unit |
| 6. Manometer | 13. Inline filters |
| 7. Safety valve | 14. Spray line |

Suction filter


The suction filter is located underneath the three-way suction valve.



3 - Description


Safety valve

It is made of cast iron and is situated on the front of the machine next to the operating unit. From this manifold it is possible to activate the agitator and the rinsing nozzle for internal cleaning (optional), as well as the Turbofiller (optional) or powder mixer. Do only open the manifold valve in order to send pressure to the desired device, as example given the Turbofiller.




Pressure manifold

It is made of plastic and is situated on the front of the machine next to the operating unit. From this manifold it is possible to activate the agitator and the rinsing nozzle for internal cleaning (optional).



Suction and pressure pulsation dampers


The 321 pump is fitted with a pulsation damper on suction and pressure sides. The pressure side damper is pressureized. The dampers will reduce pulsations and secure an even flow from the pump.



Agitator

At the front and on each side of the inside of the tank there are two ventury-shaped agitators. The agitators are activated by a valve on the pressure manifold.

Each agitator has a \varnothing 3mm nozzle (D).



3 - Description

Operating unit

Your sprayer will be equipped with operating unit accordingly to country specifications.

The mistblower can be equipped with following types of operating units: MC/2, CB/2, SV and CB.

MC/2 operating unit

It has two section valves which control RH and LH sides. The section valves are remote controlled from the tractor cab by via two bowden cables.

SV operating unit

2 or 4 section valves, by means of solenoid valves for on off of each section. The SV operating unit has no pressure equalization device. Pressure regulation is done manually in the working zone.


CB operating unit

Electrical remote pressure regulation, section valves by means of motor valves with pressure equalization device.

Filters

The pressure filters are located on the bumper next to the air outlet nozzle. In the HLC circuit the filters are made of plastic and in the HPC circuit they are made of brass.


All filters should be kept in good condition and cleaned regularly. Make sure you to use correct combinations of filter and mesh size. The mesh size should always be less than the average of the total flow from the nozzles.



Powder mixer

This is used to rinse the filter basket intank's filling hole when adding powdered products that do not dissolve properly form lumps on contact with the water in the tank.

After using the powder mixer it must be disengaged as it uses a large amount of the available pump capacity.



3 - Description

TurboFiller

Chemical inductor, TurboFiller (optional)

The TurboFiller allows filling of both powder and liquid spray chemicals safe and conveniently when standing next to the machine.

The Turbofiller must be neatly stowed away to the bay under the main tank when not in use.



ATTENTION! Local legislation may require chemicals to be filled by use of a chemical inductor. Always follow local legislation into force at any time.



TurboFiller suction valve

The valve is used simultaneously with the TurboFiller. The valve has 2 settings: In the position A, indicated on the picture, it is closed. Open the valve when chemicals are to be filled into the TurboFiller.




TurboDeflector valve

This TurboDeflector valve activates the Vortex flushing of the TurboFiller. Lift the lever to lock it in open position for continuous liquid rotation in the hopper.



Start TurboDeflector



Chemical Container Rinsing lever

The upper lever is used for two purposes:

When the TurboFiller lid is open: For rinsing empty containers. Place the container over the rotating flushing nozzle in the middle of the TurboFiller to rinse the inside of the container.


When the TurboFiller lid is closed: Use the Chemical Container Rinsing lever to rinse the hopper when the filling of chemicals is completed.



Chemical Container Rinsing



DANGER! Do not press the lever unless the multi-hole nozzle is covered by a container as spray liquid may otherwise hit the operator.



3 - Description

Axial blower units



Technical information

The air kits fitted on the HARDI ZATURN mist blowers are the AG820 and AG920, both having a polyethylene housing and fan blades made of a hardened synthetic material. Their aerodynamic shape offer a high quantity and perfect air distribution, low noise levels and low power consumption when adjusted to standard levels. The fan clutch enables a smooth start and stop.

EF820, EF920, AB750, AB820, AB920, AG820, AG920, IAG820, IAG920, SF65, SF85 and XF90

The air kits are fitted with a grid with air guides at the air intake, which forms the air flow before reaching the fan, to decrease the imbalance in the airflow. The fan is either 820 or 920 mm of diameter and is fitted with blades made of a hardened synthetic material. This reduces the power consumption to a minimum as a result of low material density.

There is a channel between the air intake and the cone of the air kit which increases the air speed through the outlet, and ensures that a high uniformity in air distribution is achieved.



3 - Description

Aif flow for axial air kits

	Blower unit	Speed	Relationship	Fan diameter	Power		Air flow	
					kW	Hp	m3/h	cubic foot/minute
NEPTUN	iEF750	1 gear	1:4.4	750 mm / 30"	25	35	28.000	16.500
	EF820	1 gear	1:4.4	820 mm / 32"	25	35	35.000	21.000
	iEF820	1 gear	1:4.4	820 mm / 32"	25	35	31.000	18.000
	EF920	1 gear	1:4.4	920 mm / 36"	33	45	45.000	26.000
	iEF920	1 gear	1:4.4	920 mm / 36"	33	45	40.000	23.000
	AB820	1st low 2nd high	1:3.5 1:4.4	820 mm / 32"	25 32	35 44	36.000 43.000	21.000 25.000
	AB920	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	27 33	38 45	42.000 50.000	25.000 29.000
ZATURN	iAB750	1st low 2nd high	1:3.5 1:4.4	750 mm / 32"	19 25	27 35	26.000 33.000	15.000 19.000
	iAG820	1st low 2nd high	1:3.5 1:4.4	820 mm / 32"	26 30	36 42	34.000 40.000	20.000 24.000
	AG820	1st low 2nd high	1:3.5 1:4.4	820 mm / 32"	27 33	38 45	43.000 50.000	25.000 29.000
	AG920	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	30 36	42 50	51.000 60.000	30.000 35.000
	iAG920	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	30 36	42 50	46.000 54.000	30.000 35.000
JUPITER	SF65	1st low 2nd high	1:3.5 1:4.4	820 mm / 32"	41 40	56 55	55.000 65.000	32.000 38.000
	SF85	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	37 44	51 60	72.000 85.000	42.000 50.000
	XF90 low pitch	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	37 42	50 58	70.000 80.000	41.000 47.000
	XF90 Medium pitch	1st low 2nd high	1:3.5 1:4.4	920 mm / 36"	44 52	60 70	85.000 100.000	50.000 60.000

Protective grid

The air kits are fitted with protection grids. They are fundamental for avoiding accidents and for stopping foreign bodies from getting inside the air kit.



Tractor drivers seat is the intended working place during operation.





This product is designed and should be used in orchard products application.



Do never pass 540 rpm on tractor PTO.

Invers air inhalation

A is air inhale and **B** is air out let



3 - Description


-  DANGER! It is strictly forbidden to use the blower unit without the protective grid.
-  DANGER! Do not approach the fan when in use.
-  DANGER! Do not introduce foreign bodies through the grid, regardless of whether the fan is in use or not.
-  DANGER! During the working day, protect your hearing from the noise produced with EN 352-1:1992 approved hearing protection or similar.
-  DANGER! If you notice vibrations or unusual noise, stop the fan immediately and consult your HARDI dealer.




Deflectors

Axial air sprayer as well known as air sprayers can optionally be equipped with mentioned deflectors.

Deflectors contribute to an increased efficacy in the spray job, as they reduce drift, and provide direction of air and spray mist to the target, according to adjustment.



Top



DUO P



DUO T



JET

3 - Description


Gearbox

The AG820 and AG920 are fitted with a 2-speed gear box with a neutral position. The front and lower area of the gear box are attached to the chassis. It is fitted with a speed selector that prevent from jumping out of gear when engaged.

The speed ratios are following:

1st speed, low gear: 1 – 3.6


2nd speed, high gear: 1 – 4.4



Fan

The axial fan has syntetic, impact proof blades resistant to high and low temperatures as well as chemical products.

The blades have 3 different angle settings to adjust the air flow. To change the angle see the section 'adjusting the fan'




Specific for SF and XF axial fans

After changing pitch, the fan needs to be balanced.

Position P1 (35°) must coincide with C1, in other words the first groove on the fan blade with the first groove on the crown.

Second position P2 (40°, standard factory setting) must coincide with C2.

Third position P3 (45°) must coincide with C3.



3 - Description

Centrifugal Blower Units

General information

The blower unit is located at the back of the machine. It contains a gearbox unit, blanking plate, crankcase, outlet hoses and nozzles, turbine and clutch.

There are two different turbine models: the steel model assembled in P540 and P540D centrifugal blower units, and the aluminium model assembled in HF600 blower units.



ATTENTION! The clutch is one of the most important parts in the blower unit in terms of safety. Make sure that it is in perfect conditions (i.e. that it is not blocked, etc.). Otherwise, it could cause the blower unit to explode.

HF540 (TS3 P540 / TS6 P540 Single)

HF540D (TD3-P540 Double)

HF640D (TD3-P640 Double)


The air kit should adapt to the requirements of the booms width and crop in order to give the best application results. The following section gives more details about the different pneumatic air kits available.

The letters HF***D means High Flow and Double, respectively. They have a polyethylene crankcase.

Crankcase and turbines with 540 mm / 21" or 640 mm / 25" diameter.

Components

- | | |
|---------------------------|------------------|
| A. Grid | D. Steel turbine |
| B. Polyethylene crankcase | E. Gearbox |
| C. Clutch | F. Chassis |



DANGER! UNDER NO CIRCUMSTANCES should you exceed 540 r.p.m. from the tractor PTO as there is a serious danger of air kit explosion.



DANGER! STAY CLEAR of the air inlet and outlet while the turbine is in use. Foreign objects could be expelled from the air outlet or parts of clothing could be sucked into the air inlet.



WARNING! The blower units are the most dangerous part of the machine. Do not attempt to alter any of its components without checking with your nearest distributor first. Manipulating blower units to change their characteristics should only be carried out by qualified personnel that has been expressly authorised by ILEMO-HARDI S.A.U.

3 - Description



Air flow of HF540, HF540D and HF640D centrifugal turbines

Blower unit	Speed	Relationship	Turbine diameter	Power		Air flow	
						m ³ /h	cubic foot/minute
HF540	1st low	1 - 6.6	540 mm	12 Kw	16 HP	8.000	4700
TS3 P540 / TS6 P540	2nd high	1 - 7.8		16 Kw	21	10.000	5900
HF540D	1st low	1 - 5.7	540 mm	14 Kw	19	11.000	6500
TD3-P540	2nd high	1 - 6.6		22 Kw	29	15.000	9000
HF640D	1st low	1 - 4.5	640 mm	24 Kw	33	27000	16000
TD3-P640	2nd high	1 - 5.7		36 Kw	49	37000	22000

Protective grid

The blower units have protective grids fitted to the air inlets. They are essential for avoiding accidents and preventing small stones, leaves or other foreign bodies from entering the blower unit that could cause damage inside the grid.

-  DANGER! It is strictly forbidden to use the blower unit without the protective grid.
-  DANGER! Do not approach the fan when in use.
-  DANGER! Do not introduce foreign bodies through the grid, regardless of whether the turbine is in use or not.
-  DANGER! During the working day, protect your hearing from the noise produced with EN 352-1:1992 approved earmuffs or similar.
-  DANGER! In the case of vibrations or knocking, stop the turbine immediately.



3 - Description

Gearbox

The HF540, HF540D and HF640D blowers have a two-speed gearbox with neutral position.


Upper pos: High speed

Middle pos.: Neutral

Lower pos.: Low speed



DANGER! Do not attempt to engage or disengage the speed with the PTO in operation.




HF540, HF540D and HF 640D Turbine

The HF540 and HF540D centrifugal blower units contain a galvanised steel turbine. The difference between the single model and the double model is that the double provides the same power as two single turbines combined.

The position of the blades in this type of turbine is fixed. Their angle cannot be changed like in axial fans.

The turbines are allowed to turn at a maximum of 540 r.p.m.

The clutch is in the centre of the turbine, which ensures smooth start-up and stop. See section "Clutch" for further information.



Clutch (All blower types)

The clutch is integrated at the centre of all the fan models and will ensure a smooth start-up and stop of the fan. The clutch design may vary from model to model, but the functioning and maintenance is the same.



WARNING! The clutch is a vital part in the blower unit. Poor condition could cause the blower unit to break or explode. The condition of this part should be regularly checked. Please carefully read the section 'Maintenance'.



DANGER! The clutch is one of the most important parts in the blower unit in terms of safety. Make sure that it is in perfect conditions (i.e. that it is not blocked, etc.) Otherwise, it could cause the blower unit to explode.




Equipment

Ring drawbar

This is attached near the tractor's rear axle. Before engaging the tractor PTO (Power take-off), make sure the drawbar pin is firmly in place and secured, and that the tractor's wheels do not touch the mistblower when turning.


There needs to be a CV joint on the side of the tractor. The length of the drawbar can be adjusted (see section "Adjusting the length of the drawbar").



Fork drawbar

This is attached to a transversal hole boom fitted to tractor's lift arms. Before engaging the tractor PTO make sure the drawbar pin is firmly in place and secured, and that the tractor's wheels do not touch the mistblower when turning.

A CV joint is not required. The length of the drawbar can be adjusted (see section "Adjusting the length of the drawbar").



Turnable drawbar




This is attached to the tractor's lift arms. Before engaging the tractor PTO make sure the diameter of the shaft fits the ball couplers at the lift arms. Also make sure to fit the securing pins and check that the tractor's wheels do not touch the mistblower when turning.

This type of coupling allows narrow turns, if a CV joint is fitted at the mist blower's power intake. The length of the drawbar can be adjusted (see section "Adjusting the length of the drawbar").

The turnable drawbars, model X and Y are fitted under the rear axle of the tractor, a common arrangement on smaller fruit orchard models of tractors. Important that the two stop bolt are tighten up, to avoid slack



Always stop PTO before making a tight turn even with a wide angle transmission shaft fitted. Tight turns with PTO engaged may damage the transmission shaft, the pump crank shaft and induce huge vibrations through the gearbox. This may lead to severe damages on gearbox and/or fan.




Selfsteering drawbar.

3 - Description

Wedges

The wedges are located on the left-hand side of the machine. They should always be carried in their support so they are available when required.



Light kit

The light kit can be fitted to the rear bumper at the fan. They are connected via a universal plug adaptable to any make and model of tractor.



Lights must be used when driving on public roads both inside and outside urban areas. If any of the components would break, they should be replaced immediately. In order for the device to work, connect the plug to the light socket on the tractor.



Booms

Hardi offers 4 booms programs , LINER , ATLAS , BOXER or CRONOS.

The booms are equipped with pneumatic or hydro pneumatic spouts or IRIS drop legs.


If hydraulic folding and adjustment is offered , it is direct to the tractor or electro hydraulic , see separate chapter.

The LINER boom

Manual adjusted support to position spray device either behind the turbine with the FIX system, or on each side of the turbine unit, the START system. Both can be combined to START FIX boom system.

Optimally, last mentioned can be offered with hydraulic side adjustment.

An in-between row solution.




3 - Description

The ATLAS boom

The boom program is divided in following versions , START, AGILE and SOLID.

According to specification, hydraulic adjusted , The SOLID addition is as well offered in a GV version, Geometry Variable.




3 - Description

The BOXER boom

3 additions , START, AGILE and SOLID

Hydraulically adjusted the first have a light structure and SOLID is reinforced and wider boom structure.



3 - Description


The CRONOS boom

The boom program is divided in the following versions , SOLID, RIDER and VARIA


According to specification, hydraulic adjusted. Common for all booms is the rubber bump absorber in the boom wing. SOLID has no trapeze suspension. RIDER & VARIA has trapeze suspension.

All 3 versions of the CRONOS boom are offered in FIX boom wing (no angling – Tilt function in boom wing, or GV boom wing (Geometry Variable) allows Tilt up in positive 60° and negative -25° down to adapt to the target.


The inner spray device can optionally be hydraulic adjusted but the “ADAPTA” as well as the outer device can optionally be hydraulic adjusted




CRONOS SOLID




CRONOS SOLID GV




CRONOS RIDER



CRONOS RIDER GV



CRONOS VARIA



CRONOS VARIA GV


3 - Description

Break away clutch

All boom wings are equipped with brake away clutches, in vertical as well as horizontal direction, according to boom specifications


The clutch is adjusted according to boom weight and field conditions.

Soft and loose the clutch. Loosen counter nut A, loosen bolt B. To tighten clutch to be harder; loosen nut A, tighten bolt B. Tightness must never be harder than 15 Kg / 30 pounds, or the outer boom wing will open / activate the boom clutch.



Particulairly for CRONOS boom

The boom's wirn is equipped with a non-adjustable rubber sustention B, to absorb the knocks from driving in the field. Be sure that the rubber parts are intact, and bolts are in place with the part well threaded over the bolt.




3 - Description

Pneumatic spray system

The pneumatic system is low pressure. This system takes advantage of the high air speed in the spout outlet to break the spray liquid and give a very fine mist together with turbulence. Using the deflectors at the spout outlet, the mist means that the liquid is distributed uniformly.

There are four spout models, which can be combined according to the bar type and assembly requested for the machine:

- A. Cannon with 1 atomizer
- B. Spout with 2 atomizers
- C. Spout with 3 atomizers
- D. Spout with 4 atomizers



The Paraflow pneumatic system is low pressure. This system takes advantage of the high air speed at the pipe outlet to break the spray liquid and give a very fine mist together with turbulence. Using the deflectors at the tube outlet means that the liquid is distributed uniformly.


There are two Paraflow models, which cannot be used together, according to the bar type and assembly requested for the machinery:

Paraflow tube with 4 in-line atomizers

Paraflow tube with 6 in-line atomizers



ATTENTION! Ceramic nozzles are used for the standard pneumatic system and the paraflow system. This type of nozzle has two positions. If the nozzle is fitted so that the flow enters on the flat side, less flow will be allowed than on the conical side




Hydropneumatic spray system

The hydropneumatic system is medium-high pressure. This system takes advantage of higher turbulence in the low-volume conical nozzle and sprays the liquid with an even distribution. The air reaches high speed in the spout, spraying the liquid in a fan.

There are three spout models with three or five nozzles. These two models cannot be combined.

- E. Spout with 3 nozzles.
- F. Spout with 5 nozzles.

Where not all the nozzles are required in treating the crop, the nozzles can be replaced for caps.




3 - Description

IRIS system, continuation of Hydro pneumatic system

The IRIS application system allows individual air adjustment as each outlet permits steep angling or even closing of the air supply, if necessary. The IRIS system provides the required droplet size and air conduction to the target. The most delicate and difficult part of the vine, the grape cluster, is safely treated throughout the season, due to a very easy and quick calibration with the IRIS system.

- A. Non-drip valve
- B. Nozzle
- C. Vane position indicator (angle)
- D. Air vane adjustment
- E. Air vanes




General information

Unloading the mistblower from the truck

When loading or unloading the mistblower to/from a lorry by using a lever and pulley or a crane, use the suspension points shown on the diagram and make sure the straps used are strong enough.



DANGER! Nobody must stand below or next to the machine during loading or unloading.



Before starting up for the first time

Although the surface of the metallic parts of the mist blower have been coated with a strong, protective product, we recommend you to apply a layer of anti-corrosion oil (e.g. CASTROL RUSTILLO or SHELL ENSIS FLUID) to all metal parts to avoid chemical products from discolouring the enamel, as well as to ease future cleaning.



ATTENTION! This treatment should be carried out whenever the protective layer wears off.

Counterweights

Check if it is necessary to place a counterweight on the front of the tractor, to increase the stability and steering performance.




4 - Starting up

Mechanical connections

Adjusting the drawbar length

1. Place the jockey wheel in the position indicated on the photo.
2. Loosen the three bolts (A), located in the area where the drawbar is connected to the chassis.
3. Remove the bolt (B).
4. Adjust the drawbar to the desired position.
5. Replace bolt (B), making sure that it passes through the holes in the chassis and the shaft.
6. Tighten the bolts (A) and the locknut again.



Jockey wheel

The jockey wheel allows the mistblower to be coupled to or uncoupled from the tractor. The illustration shows the position when the mistblower is detached from the tractor; when the mistblower is attached it will be stored on the left-hand side of the mistblower chassis using two pins.

The height of the machine can be adjusted by turning the handle (C).



Connecting the fork drawbar

This is attached to the transversal hole boom mounted on the tractor lower links. Before connecting the PTO make sure that the coupler is correctly attached and secured, and that the tractor wheels do not touch the mistblower when turning. A transmission shaft with CV joint is not required.

Adjust the drawbar if necessary as explained in another section.

Connecting the ring drawbar

This is attached to the standard clevis-type coupler close to the tractor body. Before connecting the PTO make sure that the drawbar is correctly attached and secured, and that the tractor wheels do not touch the mistblower when turning. A transmission shaft with CV joint is required on the tractor's side. It is possible to adjust the length of the drawbar.

Adjust the drawbar if necessary as explained on page 36.



Connecting the articulated drawbars


This is attached to the tractor's lower linkage arms. Before connecting the PTO, make sure that the diameter of the pins matches the ball diameter on the lower links, that the snap locks are engaged and check that the tractor wheels do not touch the mistblower when turning. Of the three hitch types, this is the one that permits the tightest turns, but a transmission shaft with CV joint is then required on the mistblower's power intake side. The length of the drawbar is adjustable.

Adjust the drawbar if necessary as explained on page 36.



Lock device on turnable drawbar

The turnable drawbars are fitted with a lock device, once down in forward in horizontal position; the pivoting effect is very limited. If the tractor has a weight 2 X the sprayer, it can be used in hilly conditions, where risk of tumbling the sprayer exists. But it is recommended to use the drawbar unlocked.



4 - Starting up



Coupling the driveshaft

Initial installation of the driveshaft may involve having to cut the axle to adapt it to the tractor to which it will be hitched. To hitch it for the first time, proceed as follows:


1. Attach the mistblower to the tractor in such a way that the distance between the PTO shaft and the mistblower pump is the shortest possible.
2. Stop the engine and remove the ignition key.
3. If the driveshaft needs to be shortened, pull the two parts of the shaft apart. Fit the two parts of the shaft, one to the tractor and the other to the mistblower crankshaft and measure out the length that needs to be removed. Mark the protection guards.




ATTENTION! The shafts must always have a minimum overlap of one third of their working length.




4. Cut both parts equally, using a saw. File the profiles afterwards to remove burrs.
5. Grease the profiles and reassemble male fitting and female fitting.
6. Fit the shaft to the tractor PTO and to the mistblower pump shaft.



7. Place the input part towards the tractor. Fit the chains to prevent the protection guards from rotating with the shaft.



ATTENTION! To ensure long life of the driveshaft and prevent possible damage to the equipment, try to avoid working at angles of more than 15°.



Hydraulic connections

General information

Make sure that the couplings are clean before fitting them!

After pressing the brake pedal and when the system has filled with oil, check the level of hydraulic oil in the tractor and refill if required.

 **DANGER!** Testing the hydraulic system should be done with care. Air may have entered the system and cause sudden movements.

 **DANGER!** Oil leakage: Do not use your hands under any circumstances to locate a leakage in any point in the hydraulic system. Due to the system's high pressure, the oil could penetrate the skin.

Tractor requirements

Hydraulic pressure of 180 Bar and a flow of 20 l/min or 5 gal / min.

Below you'll find a table where the boom requirements are listed as 2D = 2 double acting hydraulic outlets 3D = double acting outlets etc.

Converted to 1 Double acting outlet.

All booms offer optionally a Small Joystick S3 or S5 to cover up to 5 double acting functions into just 1 double acting outlet.

Larger booms and sprayer with Combustion circuit, are offered with V hydraulics, known as well as DAH – Direct activated Hydraulic.

Boom	Hydraulic rams	Operated by Optional or default
Liner		
Fix	N	
Start	N	
Start Fix	N	
Atlas		
Start H0	N	
Start H2	2D	S3 or controlbox
Start H3	3D	S3 or controlbox
Agile Fix H3	3D	S3 or controlbox
Solid FIX H3	3D	S3 or controlbox
Solid Convert H3	3D	S3 or controlbox
Solid GV Fix H5	5D	S5 or controlbox
Solid GV Convert H5	5D	S5 or controlbox
Boxer		
Start	2D or 3D or 5D	S3 or S5 or controlbox
Agile	2D or 3D or 5D	S3 or S5 or controlbox
Solid	3D or 5D	S3 or S5 or controlbox
Cronos		
Solid H3	3D	S3 or combus
Solid GV H5	5D	S5 or combus
Rider H3	3D	S3 or combus
Rider HV H5	5D	S5 or combus
Varia Convert H5	5D	S5 or combus
Varia GV Convert H7	7D	Combus

4 - Starting up

Electrical connections

General information


If your equipment includes an electrical component, please note the following information to correctly connect the equipment and to prevent problems when working.

The voltage required by the electrical components is 12 V. Before connecting any component, make sure that the polarity is correct.

Red wire = 12 V (+ positive)

Black wire = (- negative)

The connectors assembled on the electric components comply with the standards for the majority of modern tractors. If your tractor has another type of power supply connector, the supplied connector will need to be removed and adapted to the tractor connector.



CB/2 operating unit

Find a place in the tractor's cab where it is possible to fit the control box so you can operate it as comfortable as possible. The most recommended place is to the right of the driver's seat.

The control box must be properly attached to prevent it from being hit or from excessive vibrations.

The connector type is universal and it should be able to be connected to any tractor. Do not hock into coincidentally wires in tractor cabin, as it will not secure stable power and current.

Minimum requirement: min 11V max 13 V

Amp. Per SV section 2.5

Amp. Per CB section 0.75

As an emergency solution, remove the connector and splice the wires directly to the battery, remember to have fuse in-between.



The control box must be properly attached to prevent it from being hit or excessive vibrations.

The connector type is universal and it should be able to be connected to any tractor.

As an emergency solution, remove the connector and splice the wires directly to the battery.




WARNING! Always remember: Red wire (+) Black wire (-)




DANGER! Always turn off any spray computer before you unplug the power supply and cable to the sprayer.

Data transmission must stop, before power supply is stopped.



Rate controller


Rate controller DB 3610



The Job boxes for input and out put signals

4 - Starting up

Rate controller DB 3620



The Job boxes for input and out put signals


Fluid circuit

Suction filter

The mesh size of the standard filter is 50 mesh. 80 and 100 mesh filters are available and can be changed by opening the top lid of the filter. Check the O-ring before replacing the lid and replace it if it is damaged.



ATTENTION! For better sealing between the lid and the O-ring, coat the area between the joint and the lid with grease. This will make the O-rings seal and avoid suction of false air.




Pressure damper

The air pressure of the pulsation damper (321 pump) is factory-set at 2 bar to match spraying pressures between 3 and 15 bar.

When spraying with different pressures than this, you must change the pressure of the damper. Follow the list to adjust it to the correct pressure. This table is also engraved on the damper.


Spraying pressure bar	Pulsation damper air pressure bar
1.5 - 3	0 - 1
3 - 15	1 - 3
15 - 25	3 - 4



Diaphragm pump

Before starting to use the machine, make sure the diaphragm pump is well greased to prevent wear.

The pump is greased from factory, but should be greased again during bedding in and then every 50 hours.



4 - Starting up

Deflectors




ATTENTION! Never access area or adjust deflector or any other part near the air kit, while tractor is started.

V deflector

Park the sprayer in the orchard, between 2 tree rows, adjusted is visually to point towards the tree top.

Tight up adjustment bolts, test with clean water. And verify target is well sprayer.




Top S or L

S the short version L the slightly higher version.

Parked between rows, orientate the adjustable air outlet towards the target, and test with clean water.

Top S adjust from 90° to 50°


Top L adjust from 110° to 70°



Adjustable bottom deflector

Allows to drive the upwards, and avoid air turbulence on the ground and stem, as often used in e.g. plum orchards

Adjust it between rows, test with clean water.





4 - Starting up

Adjustable bottom deflector

Allows to drive the upwards, and avoid air turbulence on the ground and stem, as often used in e.g. plum orchards

Adjust it between rows, test with clean water.



4 - Starting up

DUO P deflector

Fixed position of air outlet, nozzle holders placed in front of the air outlet, easy accessed for calibration.



DUOT and V deflector

Provide adjustability in the top of the deflector, to secure direction of air and spray mist towards the target. Loos the hand wheel, position the adjustable part in visual direction to the target, tighten up the hand wheel and test with clean water.



JET deflector

Provide adjustability in the top of the deflector as well in the lower part.

Loosen the bolts of the adjustable bottom and top part, adjust it visually towards the target, tighten the bolts and test with clean water.



Booms


General information

All the booms have either minor or major options to adapt to the crop, all according to the technical level of the boom structure.

FIX

The FIX boom, provides height and width adjustment of spraying device by loosening the bolts X and Y, positioning the spray device and tightening again.

Width adjustment from 7" to 40".




START

Provides telescopic width adjusted by loosening the bolt in pos. X. Once positioned, tighten the bolts again.

Width adjustment from 1.1 m to 1.8 m or 40" to 72"

The extreme part of the START boom can be equipped with 60° angling bracket, depends of chosen spout set up. Remove pin bolt in pos. X and poisoning according to the crop.


The bracket as well allows to be turned 180° down wards by loosening bolts A



4 - Starting up

ATLAS START

Provides adjustment of outer spray devices from 10ft to 13ft as well as in center section, left and right plus minus 8" or 20 cm. In Metric: booms adjust from 3.1 m to 3.9 m in section A on the drawing, and central parts section B, adjust 0.2 m in both sides. Loosen up fixation bolt in mentioned A and B area adjust and tighten again.




ATLAS AGILE

Boom wing width as ATLAS START, but combines with the FIX boom bracket

ATLAS SOLID FIX and ATLAS SOLID FIX GV

The boom wing width adjust from 13,7 ft. to 18ft or 4,2 m to 5,5 m

The centre section is the FIX system, consult description above.



ATLAS SOLID CONVERT and ATLAS SOLID GV CONVERT

Same boom width as above, ATLAS SOLID, for adjustment of CONVERT boom part. Consult description above.


4 - Starting up

BOXER START

Boom wing telescoping hydraulic adjustment from 8.5ft to 12.7ft

Or 2,6 m to 3,9 m


Adjustmet of center section , see rele mavnt description under ATLAS START.



BOXER SOLID VERTICAL FIX or CONVERT

Telescopes from 11.8ft to 15.7ft or 3,6m to 4,8m


Rear part FIX or CONVERT side adjustment, consults the respectively description above.



BOXER SOLID HORIZONTAL

Telescoping boom from 1,8 m to 5,4 m or 5.9ft. to 17.7ft.

Rear part FIX or CONVERT side adjustment, consults the respectively description above.




4 - Starting up

Adjustment of BOXER boom

Important to avoid destructive slack in the telescoping part, the slack must be adjusted.


Loosen counter but A tighten in bolt B, not the press into the telescoping boom part, but just hold it firm and avoid slack. Tighten counter nut again.

Grease the part every 200 hours or annually.



The indicated nylon friction parts must be kept clean, avoid sand and dust in them.

Replace when worn.




CRONOS BOOM

Exist as SOLID , RIDER , GV or VARIA

SOLID

7.1 me boom width, the spray device can easily be positioned on the boom with and or in the centre section.

The booms wing is equipped with a non adjustable rubber suspension, to absorb the knocks from driving in the field. Secure the rubber parts is intact, and bolts are in place with lock part threaded well in over the bolt.




4 - Starting up

RIDER

Has additionally to the boom wing rubber suspension, as well trapeze suspension in the centre section.

Keep moveable part free from dust and dirt, grease weekly / every 50 hours.




VARIA

The CRONOS VARIA provides hydraulic side adjustment, from the driver position.

The central part A is telescoping 0.65 m (26") to left and to the right side.

Secure the telescoping part is well lubricated, and all ways kept clean from sand and dust. The telescoping part is guide in nylon friction pads, secure they are in proper.



Once the VARIA system is telescoped out, it is not permitted to fold the boom, all ways recall the VARIA system and then fold.

The drawing illustrates the VARIA system telescoped out to max position.



CRONOS GV

As the RIDER and individual boom wing tilt.

Outer boom element can as well be positioned sideward, optionally with hydraulic piston.

4 - Starting up

General for all boom models


Break away clutch

All boom wings are equipped with brake away clutches, in vertical as well as horizontal direction, according to boom specifications

The clutch is adjusted according to boom weight and field conditions.

Soft and loose clutch. Loosen counter nut A, loosen bolt B. To tighten clutch to be harder; loosen nut A, tighten bolt B.


Tightness must never be harder than push of 15 Kg / 30 pounds, on the outer boom wing will open / activate the boom clutch.



Adjustment of hydraulic fold

To achieve the correct folding position of the boom wing, the folding cylinder must be adjusted.

Undo the counter nut A, remove the cylinder eye B from the position, turn it either further in or out accordingly to find the right position of the boom in transport as well as in working / spraying position




4 - Starting up

Transport bracket

The transport bracket must secure the boom wing in transport. To position it, loosen the indicated bolts, and adjust to the firm resting position of the boom, and tighten bolts again.

Inspect weekly the transport bracket, and secure the nylon friction parts are intact.




Adjustment of upright

The upright needs to be adjusted for slack between the male and female tubes.

Tighten on the two indicated nuts, just to make it press gently on the inner male tube, if too tight it will not be moveable, too loose it will have destructive slack.


A nylon friction part is pressed towards the inner male tube; keep it clean from dust and sand. Replace the nylon friction part when worn.



Adjustment of out spray device

The out spray device is easily adjusted


The manual version is by loosening the indicated bolt A, move it to the desired position, and tighten again the bolt.




4 - Starting up

The hydraulic version

Make sure the indicated bolt B is not pressing hard on the sliding part, the black nylon roller must run freely in the rail.




According to the spray device, the outer positioning is as well as in the picture. To adjusted to desired poisoning, loosen the indicated bolt, A, move the spray device to correct position, tighten bolt again.




Adjustment of inner 4 spray device

The optional S bracket, as indicated by the arrow in the photo, can be mirrored 180° Thereby the spray device is able to be positioned behind the sprayer.

Undo the 2X 4 bolts, turn the bracket 180° and fit all bolts again.



The Convert brackets provides a telescoping side adjustment, loosen the indicated bolts, slide the inner boom tube to desired position, and tighten again the bolts, just enough to let the nylon friction pads press and hold it in position.




4 - Starting up

Hydraulic adjustment of the Convert brackets

Optionally the boom can have the side adjustment hydraulically, done from the tractor cabin.

In that case let the above indicated friction pads be just as loose as to allow the inner tube to slide in and out easily.



IRIS system setup

The IRIS application system is standard equipped with ceramic hollow cone nozzles. Each drop leg holds 8 nozzles per drop leg. If a curtain area of the canopy is not meant to be sprayed, a small valve is fitted as per two nozzles that allow turning of the spray mist. If only one nozzle is needed in that area it is as well possible to fit a blind cap.



In the valve A that allows the spray mist to pass on the nozzle, there is a small no-drip valve, that secures when the main switch turns off the spray mist, that all nozzles stop instantly, and do not spill on the ground.

The nozzles B are fitted in an adjustable support, in order to angle them forward accordingly to forward speed, and thereby not losing spray mist behind the sprayer.

The air outlet has an indicator C that shows the angling of the air vanes E which are adjusted by pressing bottom D in, and then move up or down the vanes E.

The air outlet in the lower part shall be orientated upwards to get the spray mist penetrating from down and upwards. The upper spout shall point downward in order to avoid drift. Those settings are accordingly to get the canopy, and adjustment is necessary during the season, as the size of the canopy changes.


In order to get the optimal cross flow effect and penetrate the canopy the IRIS drop leg shall be set 10°, 15°, 20° or 30° forward, as indicated in the adjustable part in the top of the drop leg. The forward angling is set accordingly to forward speed while spraying.



4 - Starting up

Cannons

On CANNON models, there are three different spout types. Model L is only fitted on variants with one turbine. It comprises 4 bi-jet holders with two nozzles each. In addition to the spout nozzles there are three adjustable nozzles outside the spout which allows to treat the nearby crops also.



Model T is fitted on variants with two turbines. It has 7 bi-jet holders in a star-shaped pattern with three nozzles each. In addition to these nozzles, there are three adjustable nozzles outside the spout which allows to treat the nearby crops also.



Model M is fitted on variants with two turbines. It comprises an outlet of 10 nozzles and there are two more with three nozzles each. You can adjust the direction in which the ends of the upper and lower spouts point.




Calibration

Enter to www.hardi-international.com and download the Excel programme for calibration.

The working distance given in, is total sprayed distance. If two rows of 1,8 then multiply by 2 that equals 3,6 m.

Check your speed.

See as well mistblower technique on www.hardi-international.com



Blower unit

Safety information

The fan must not be in operation when driving on public roads. The nozzle opening function should never be used on public roads. Any failures could cause injury to persons and animals or damage to crops. In the event that the machine needs to be in operation (agitation) while driving along public roads until reaching the field, make sure that the gearbox speed selector is switched to neutral position.



DANGER! If any unusual noise or excessive vibration in the air kit is detected then stop the equipment immediately and have it serviced by an authorised HARDI technician.



Selecting the gear

The low or high gear can be selected using the specially designed lever.

On the rear, left-hand side of the machine the selection lever is accessed between the tank and fan.

To change the speed, pull the lever outwards (A) and then move it up or down as required. Lock the lever in the selected position (at the lid).



Bottom position: 1st gear or low speed (1).

Top position: 2nd gear or high speed (2).

Centre position: Neutral (0).



ATTENTION! Do never drive and fold booms at same time. Never maneuver the sprayer unless the boom is 100% unfolded, otherwise the upright will be damaged. When the boom is folded, it must rest on transport bracket before driving.



5 - Operation



While moving the Sprayer

The booms must be 100% unfolded or resting in the transport bracket.

The boom must unfold, and stay firmly, stiff, not wobbly . If the boom is not held firmly unfolded during spraying, it will auto destroy structure due to movements, caused from lack of firm position.

See maintenance and starting up (Adjustment of hydraulic fold).

Secure folding cylinder is correctly adjusted, and eventually stop positions / stop bolts, are adjusted correctly in order to secure the boom stays stiff and firm while working. To underline, eventually trapeze or pendulum suspension, must be activated, not looked , it must be movable and floating.



Adjusting the fan A6820 and SF65/SF85 and XF90

The angle of the fan blades can be adjusted to 4 positions. The factory setting is pos. 3 (40°). Decreasing the angle of the blades (minimum angle, pos. 1 (30°)), reduces the air flow and power consumption. Increasing the angle (maximum angle, pos. 4 (45°)), will increase the air flow and power consumption. It allows the mist blower to be adapted to the different spray jobs and tractor sizes.


To change the angle of the fan blades you should follow these steps::

1. Loosen the Allen screws without taking them out completely.
2. Loosen the Allen screws whilst holding the nut at the back of the fan.
3. With both hands on opposite blades, turn them to the desired position between 1 and 4. All the blades should turn at the same time.
4. Finally, check that all the blades are in the correct position.
5. Tighten all the screws.



IMPORTANT The fan must be calibrated correctly after changing pitch setting.

For technical details ask your dealer and factory.



Single side blinds (Optional)

The air stream can be blocked to one side to prevent spraydrift towards sensitive areas.

This is used when one section valve is shut during spraying along orchard edges, streams, open waters or other sensitive areas where spray drift must be kept away.

Loosen the nuts, slide the blind over the air outlet and tighten the nuts again.



ATTENTION! Only blind one side at the time. Never close both sides at the same time!



5 - Operation

Fluid circuit

Filling/washing location requirements

When filling the sprayer with chemicals and water it is important to avoid spot contamination by spray chemicals in order to protect the subsoil water resources.

- A. If the mistblower is always filled at the same place, a special filling/washing location should be established. This should have a hard, liquid-impenetrable surface (e.g. concrete) securing against seepage and edges securing against run-off to the surrounding areas. The place should be drained to an adequate receptacle (e.g. slurry tank or similar).

Any spillage or washings should be retained and diluted in order to be distributed on a larger area to ensure minimal environmental impact and avoid build-up of larger chemical concentrations at one spot.

If no other requirements of distances exist, the following general recommendation of distance could be used. Not closer than:

- 1) 50 metres from public water supplies for drinking purposes,
 - 2) 25 metres from non-public water supplies for drinking purposes, treatment sumps and cesspools of drainage systems, and
 - 3) 50 metres from surface water (watercourses, lakes and coastal waters) and from nature reserves.
- B. Alternatively the sprayer can be filled in the field where the spraying is to take place. If so, choose a different location for each refilling.

If no other requirements of distances exist, the filling should not be established closer than:

- 1) 300 metres from public or non-public water supplies for drinking purposes and
- 2) 50 metres from surface water (watercourses, lakes and coastal waters), treatment sumps, cesspools of drainage systems, and nature reserves.



ATTENTION! Legislation and requirements vary from country to country. Always follow local legislation in force at any time.




NOTE! It is the responsibility of the sprayer owner/operator to comply with all relevant legislation. HARDI cannot undertake any responsibilities for incorrect operation and use.

Filling with water

The tank should be filled to a third of its capacity with clean water before adding the chemical product. Always follow the instructions given on the product label!



WARNING! If spray liquid is left in the tank, for safety reasons all valves must be shut.




Filling through tank lid

The tank is filled with water through the filling hole by removing the lid located on the top of the tank. The water used should be as clean as possible to obtain best results.

Fill the tank using the filter to prevent impurities from entering the tank. For greater filling capacity, an overhead tank can be used.



DANGER! Do not place the filling hose inside the tank. Keep it out of the tank at all times and only point it towards the filling hole. If the pressure hose were placed inside the tank and there was a drop in water supply pressure, the chemical product could be syphoned back and contaminate the water supply lines, plant and well.



ATTENTION! The water supply line should be provided with a check valve as additional safety precaution. Follow local legislation in force at any time.



ATTENTION! The water supply should be provided with a meter to avoid spillage by over-filling. Follow local legislation in force at any time.

Filling the rinsing tank


The rinsing tank is integrated with the main tank.

Capacity: 90 litres for 1000 and 1500 litres main tanks, and 130 litres for 2000 and 3000 litres main tanks

The illustration shows the location of the rinse tank.




ATTENTION! Only fill rinsing tank with clean water! To avoid algae developing in the rinsing tank always drain the rinsing tank if the sprayer is not in use for a longer period of time.



Rinsing nozzle

This is located inside the main tank. When the nozzle engaged it rotates fast and spray clean water in all directions.

If the machine is fitted with a rinsing system, there is one rinsing nozzle in 1,000-litre tanks, and two rinsing nozzles 1,500, 2,000 and 3000 litre tanks.




5 - Operation

Filling the clean water tank

The clean water tank is located at the front and integrated in the main tank design. It is used for washing hands, gloves and cleaning clogged nozzles, etc.



WARNING! Although this tank is completely separate from the main tank and should only be filled with clean water, this does not mean that the water is suitable for drinking.




Drain valve

The valve for safe draining is located on the underneath of the tank. To access it, you must crouch on the left side of the equipment, where the jockey wheel is attached to the chassis when the equipment is hitched to the tractor.


To empty the tank, pull the handle towards the valve. To fill the tank again, pull the valve handle toward the front of the equipment and it will close.



WARNING! When opening the valve, take care to ensure that the liquid does not spill over your hands or feet.



To empty the residual liquid in a special tank or container for storage, the quick release A of the drain valve can be adapted to connect a hose with the fitting B so that liquid can be emptied safely.



Manifold system


A & C is spraying position

B & C is TurboFiller position

D & E is Rinsing position



F is step less agitation. 3 is Max , 0 is closed

G is 15 bar safety valve; important to pop is once in a while, especially under cleaning process, to avoid chemical residues in the tubes connected.



Filling liquid chemicals by HARDI TurboFiller (optional)


1. Fill the main tank at least 1/3 with water (unless otherwise stated on the chemical container label).
2. Turn the Manifold valve towards towards TurboFiller.
3. Set the fan gear lever to neutral position, engage the pump and set P.T.O. at 540 r/min.
4. Open TurboFiller lid. Measure the correct quantity of chemical and fill it into the hopper.
5. Engage the hopper transfer device by opening the TurboFiller suction valve and the chemical is being transferred to the main tank.



6. Engage the flushing device to flush the hopper. If powder chemicals are filled the flushing device must be open before pouring the powder into the hopper.



7. If the chemical container is empty, it can be rinsed by the Chemical Container Cleaning device. Place the container over the multi-hole nozzle and push the upper lever to the left of the TurboFiller.
8. Close TurboFiller suction valve when the hopper has been rinsed.
9. Close the TurboFiller lid.
10. Disconnect the pressure to the TurboFiller, keep agitation activated to ensure homogene concentration.
11. Engage the fan gearbox before spraying.



DANGER! Always wear face shield and other appropriate personal safety equipment when filling chemicals.



ATTENTION! The scale in the hopper can only be used if the sprayer is parked on level ground! It is recommended to use a measuring jug for best accuracy.



DANGER! In order to avoid spray liquid hitting the operator, do not press lever unless the multi-hole nozzle is covered by a container as spray liquid may otherwise hit the operator.



ATTENTION! Rinsing device uses spray liquid to rinse containers for concentrated chemicals. Always rinse the chemical containers with clean water several times until they are clean before disposal.



ATTENTION! The hopper rinsing device is using spray liquid for rinsing the hopper for concentrated chemical! Cleaning the TurboFiller must always be done when the spray job is ended and together with the entire sprayer - a cleaning after the last filling and before spraying the last tankful does not ensure a clean TurboFiller!


5 - Operation

TurboFiller rinsing

Rinsing the TurboFiller and chemical containers are done in the following two ways:

When TurboFiller lid is open

For cleaning empty containers. Put container over the rotating flushing nozzle in the middle of the TurboFiller so that the nozzle is inside the container. Press the Chemical Container Cleaning lever and the TurboFiller suction valve at the same time to activate the flushing nozzle in the middle of the TurboFiller and empty out the TurboFiller rinsing liquid.



When TurboFiller lid is closed

Use the Chemical Container Cleaning lever to rinse the hopper after filling of chemicals has ended. Press the Chemical Container Cleaning lever and the TurboFiller suction valve at the same time to activate the flushing nozzle in the middle of the TurboFiller and empty out the TurboFiller rinsing liquid. Do this 3 times and after the last flushing open the lid to inspect if the TurboFiller is empty. If not, close the lid again and press the TurboFiller suction valve until the TurboFiller is empty.



ATTENTION! The TurboFiller needs to be cleaned thoroughly after finishing spraying again to be sure it is clean before spraying other crops that may be sensitive to the chemicals just used. See section Cleaning on page 55 for details.


5 - Operation

As this manual does not refer to only one model, since HARDI offers multiple configurations of the same sprayer, the following chapter refers to the available operating units.

Power supply


Power requirement is 12V DC. Always note polarity! For proper function of the electric equipment, the wires must have the following recommended cross sectional areas and correct fuses to ensure a sufficient power supply. The delivered power connectors follows the standard of most newer tractors. If you have a tractor with another power connector, it is necessary to disassemble the connector and fit it to the actual tractor connector. The number and the type of connectors may vary on the specific

When 12 V power is taken from other places than the battery, it often changes in voltage when other power consumption is activated (Air condition on / off ventilator on the radiator on/ off etc.) That auxiliation in voltage, do affect the Spray Computer.




Installation of control unit brackets

Find a suitable place in the tractor cabin to mount the control units. Best recommended position is to the right of the driver seat.



The supplied tractor pillar bracket (A) has a hole spacing of 100 and 120 mm that fits most tractors. Threaded mounting holes may be hidden behind front corner cover. Check tractor instructions manual for information regarding attachment points. Three mounting tubes (B) are supplied. One, two or all three may be used. They can be bent and shortened. A spacer (C) is also supplied to allow further attachment possibilities. Find the best solution for your tractor or vehicle. Tube (B) plate is staggered so that, if correctly orientated, all boxes will line up.



DANGER! Always turn off any spray computer before you unplug the power supply and cable to the sprayer.

Data transmission must stopped, before power supply is stopped

5 - Operation


SB 3002 or SB 3004

The control box for SV (Solenoid Valves)

The operating unit consist of 2 or 4 sections

The operating unit SV can be equipped with remote/electrical pressure regulation or not. Most common specification of the operating unit is with manual pressure regulation.



It is in all cases a non constant pressure operating unit, also expressed as non pressure equalisation. This affect, when one section is closed the pressure in the remaining spray line change.



1. Section valves
When up = off
When down = on
2. Pressure up & down - for less pressure + for higher pressure (an optional function).

SV operating unit

1. Manual pressure regulation, turn left for less pressure, right for higher pressure.
2. The section valve. No adjustment is needed.



SB 3012 or SB 3014 etc.

Are the control boxes for motorised operating units The operating unit CB2 CB4 etc.

A constant pressure operating unit, allows to turn off one section, and maintain the pressure constant.

1. Section valves
When up = off
When down = on
2. Pressure up & down, - for less pressure and + for higher pressure.


5 - Operation

SB 3012 or SB 3014 etc.

Are the control boxes for motorised operating units The operating unit CB2 CB4 etc.

A constant pressure operating unit, allows to turn off one section, and maintain the pressure constant.

1. Section valves
When up = off
When down = on
2. Pressure up & down, - for less pressure and + for higher pressure.



FB 3610

F0. Main Switch valves section

F1-F3 / F2-F4. Fluid sections: Odd on left / Even on right

S1-S2 / S3-S4. Hydraulic selectors


P+ / P-. PRESSURE Regulation + & -

STB. ON / OFF



CB operating unit

1. Pressure equalisation device on the section valve.
Turn left, or right to increase or decrease the pressure change that occurs when turning the section off/on.
This is done once for all. If nozzles are changed, it may require to repeat the procedure.
2. Pressure regulation, no adjustment is needed.
This photo illustrates a 2 section operating unit CB2.



CB operating unit with by pass valve

The operating unit is in case of low dose rates, as often the case in pneumatic sprayers, equipped with an additional bypass valve.

Open the valve to let X amount pump flow return freely to tank, this provides a pressure drop in the system, and allows the pressure to come very low.

Clock wise = closing

Anti clock wise = opening



5 - Operation

Hydraulic control boxes

All according to boom model and specifications in hydraulic functions.


If the boom is equipped with electro hydraulic functions, the control box can be as illustrated.

Where there are more than 5 hydraulic functions on the sprayer, most common is then control boxes as HC3150 or HJ3200

The hydraulic control box, in less hydraulic functions, can be operated with a control box.

HB 3003, 3004 or 3005 all according to boom specifications.

1. Lift up & down
2. Boom wing left fold in & out
3. Boom wing right fold in & out



HB 3610

H0+ / H0-. Lift


H1+ / H1-. L Fold dépliage

H2+ / H2-. R Fold dépliage

H3+ / H3-. L Variable geometry

H4+ / H4-. R Variable geometry

STB. ON / OFF



The Joystick S selector

Remove the rubber protection in the lower end; screw it onto the hydraulic lever, by means of the nut fitted inside the Joystick.

Connect the power plug to 12 V and connect the universal connection plug to the sprayer.

Push the lever / joystick forward without pressing a button, and the lift goes up, upper site down.

Press forward the lever / Joystick, and press on top left bottom and left boom wing fold out, supersite, it folds.



Cannon L-M-T

Hydraulic engine 180° turn = 1 double acting outlet

Spout lifting cylinder = 1 double acting outlet

Hydraulic control of the CANNON

The operating ranges of all three CANNON models are the same.

The lifting cylinder is controlled via a double acting outlet on the tractor and can be set vertically between -10 to 80° compared to horizontal



The spout can be rotated 180° by another double acting outlet. This allows treatment to either side independent of driving direction.



The hydraulic adjustment


The joystick activates the solenoids on the hydraulic block.

The oil flow from the tractor is different from model to model.

Adjusted the flow on indicated Allen bolt:

in = slows down out = speeds up

The boom must move slowly in all moves.




5 - Operation

HC 3100 control box

In combination with electrical operation unit as CB.

It allows optionally vegetation sensor to be connected.


1. on / off
2. Section valves
3. Pressure regulation up & down - for less pressure + for higher pressure. Also, access to Settings, the menu where time delay and respond time to vegetation sensors are programmed. See separate manual.
4. Automatic or manual mode of the on / off function, if vegetation sensors are fitted.



Vegetation sensor is optionally equipped

Opens and closes automatically if tree or bush is detected.


A time delay in opening and closing is programmed in the control box, either HC3100 or HC3150 or HC3250.





Following pages in this instruction book, refers to Sprayers with Combustion electronic circuit.

HC 3150



1. Display screen
2. Magnifying glass - Screen shift
3. RATE CONTROLLER, ON/OFF in spraying mode || ENTER or VALIDATION on MENU navigation mode
4. Up / Down buttons.
 - I. Change the spray pressure manually
 - II. When the rate controller is activated, adjust the programmed L/ha in steps of +/- 5%. It is used to increase and decrease L/ha in areas that need more or less spray liquid.
 - III. Under these circumstances, the MENU can be used to change the values.
5. MENU button
6. ESCAPE button
7. SECTION VALVES . Up to 7 sections. Only those which have been enabled on the configuration menu are operative. In case of uneven number of sections, the central button takes section 3 – S3, S5, or S7 correspondingly.


5 - Operation

8. Main ON / OFF button of Rate Controller, but at the same time main on/off of operating unit.
 - I. If turned OFF → press 1 sec. and it STARTS
 - II. If turned ON → Click shortly, to enter in PAUSE or as well explained as STAND-BY mode. This mode is utilised to configure or access to advanced functions by technical service. When PAUSE / STAND-BY everything stops. (Rate Controller, section valves turns off, Flow, pressure and Speed signal stops. If you have a HC3250, 100% identic to HC3150, but with hydraulic functions as well, the hydraulic functions stops as well when PAUSE / STAND-BY mode is activated.
 - III. If turned ON → Press for 4 sec and the everything is turned OFF.
9. ANGLING buttons. → Used as a main function to set up the angle on piston to angle outer spouts, or used to control 2 hydraulic cylinders if needed, depends on the technical factory configuration.
10. FLUID 1 button (F1) → Used to enable / disable some functions on configuration mode, only Factory and/or technicians. In case both, 2 x hydraulic cylinders and 2 x electrical spouts, F1 button on Spray mode is used to shift from one to another function, dual function on one and same function button.
11. AUTO button → To enable / disable the sonic sensors, in case such are mounted, if used, the Rate Controller is enabled
12. CONFIGURATION button → In STAND-BY + 6 press on C the system shifts to CONFIGURATION mode. Factory or service technicians only.
13. HYDRAULIC 1 button (H1) → Used to enable / disable hydraulic functions in CONFIGURATION mode.
14. PRINCIPAL (P) button → Main on/off of sprayed mist, all sections in the operating unit

HC 3150

100% identical to HC3150, but with hydraulic buttons in extension of the buttons for the operating unit.

In order to provide sufficient hydraulic function, some hydraulic buttons have double function. To take them to level 2, press the button H1 in lower right corner of the HC3250 cabinet.




Some of the hydraulic button have two levels / two different functions, according to what layer is activated.

When H1 is not illuminated → The hydraulic button are in work mode.

The most used hydraulic function while spraying are active.

15. 15+ / 15- Lift up / Lower, the centre section.
16. 16+ / 16- Geometry Variable, Left (parallelogram Tilt up or down).
17. 17+ / 17- Geometry Variable, Right (parallelogram Tilt up or down).
18. 18+ / 18- Fold / unfold boom, left side.
19. 19+ / 19- Fold / unfold boom, right side.

5 - Operation



Press H1 and it lights up → the secondary hydraulic functions are activated.

The second layer in the hydraulic buttons, control the less frequent hydraulic function while working. It is likely the boom width, the VARIA function, or the inner adapter or the Exterior adapter.

- 20. 20+ / 20- Adapter Exterior Left (Remote processioning of left spray device).
- 21. 21+ / 21- Adapter Exterior Right (Remote processioning of right spray device).
- 22. 22+ / 22- Adapter Interior, Left .
- 23. 23+ / 23- Adapter Interior, Right.



Attention: the centre buttons acts according to the last activated "left / right" button, it does the recall of what just was done.

- 24. 24+ / 24- VARIA centre section, Left.
- 25. 25+ / 25- VARIA centre section, Right.

5 - Operation

HJ 3200 Joystick & HC3050

100% identical to HC3250 but split in 2 cabinets, the spray computer HC3050 and the Joystick HJ3200.



In occasions with more than 6 hydraulic function, the H1 button is briefly pressed, that provides a second level of all hydraulic buttons, thereby same button get to different function, all according to the activation of level 1 or level 2.

The plus + minus - buttons on the back side of the joystick are for pressure adjustment.

The + / - buttons are as well for factory programming. While the system is in programming mode, you press the plus button as many times as you have hydraulic pistons on the machine. Only to be done by trained technicians and factory.


See other booklet for programming, as well as tutorial videos.



HC3050 has same Spray Computer functions as HC3150 and HC3250, it is the upper half of those.



  The plus / minus buttons are placed on the back side of the grip.



5 - Operation

Work menu

The system is split into 2 operators menus and 2 factory menu.


WORK MENU, CONFIGURATION MENU & FACTORY MENU -not in the daily user's manual.

The functions used while spraying.

It is split into 4 screens which can be accessed using the magnifying glass.


Main 1

Screen



Field

3 Screens = 3 displays of programed settings



Limits

1 Screen



Set the min. & max values of the regulation range / window




Konstants for sensors

1 Screen

Enter the PPU for, Speed, flow, etc.



Rate controller DB3610 and DB3620



- | | |
|----------------------|--|
| 1. Tank shortcut | 14. ON/OFF sonars |
| 2. Pressure shortcut | 15. ON/OFF/Pause |
| 3. Velocity shortcut | 16. Pressure |
| 4. L/Ha shortcut | 17. Flow in litres per minute |
| 5. Change screen | 18. Speed |
| 6. Autonomy shortcut | 19. Tank level |
| 7. L/min shortcut | 20. Application dose R-real P- programed |
| 8. Land shortcut | 21. Remaining capacity according to tank level |
| 9. Menu/Left | 22. Time |
| 10. Up | 23. Tank level |
| 11. Escape/Right | 24. Rate controller in ON or OFF |
| 12. Down | 25. Optional vegetation sensors |
| 13. Enter/Regulator | 26. Section of operating unit |

Above picture illustrates the rate controller / Spray computer DB3620.

It is the largest in the rate controller family 3600, with colour display. The rate controller DB3610 is very similar in function, but smaller on the screen in black and white, versus the larger in colour.

The functionality of the smaller DB3610 is identical,

5 - Operation


Example of speed and pressure limit settings

The pressure limits are set to 5 and 9 Bar, and speed limits are 2 and 6 km/h.

The pressure will not reach 11 Bar, the limit is 9 Bar.

If speed is higher than 6 km/h the rate controller will not push up the pressure, as the programed max speed is 6 km/h.

Spray mist continues to flow through the nozzles, when we are beyond the limits, in the "Dead zone" but the programed dose rate is no longer achieved. If speed is higher than the limit, we apply less dose rate per Ha. as the pressure do not follow the high speed.



Adjusting the BK/2 Operating Unit




ATTENTION! It is very important that the operating unit is well adjusted. Before using the equipment for the first time, it is necessary to adjust the constant pressure valves at each section valve.

During this procedure, the individual return capacity of each section is adjusted, so that it returns the same amount of liquid that would normally be sprayed through all the nozzles at the section when open.

This avoids variations in pressure when one or both sections are shut. The adjustment procedure is the following:

1. Open both sections via the lever taps.
2. Set the pressure at, for example, 3 bar.
3. Close one of the Sections.
4. Adjust the constant pressure valve of the closed section valve until the pressure gauge indicates 3 bar again.
5. Open the section valve again and repeat this procedure for the other section valve.
6. Verify the adjustment by opening both sections at the same time or one by one. If the operating unit is correctly adjusted the pressure always remains unchanged.



ATTENTION! It is recommended to carry out this adjustment as close to the intended working pressure as possible.



ATTENTION! Carry out this adjustment every so often as somebody may accidentally change the position of the pressure equalisation valve



ATTENTION! once the pressure adjustment has been performed, it only needs readjustment when:

1. Another nozzle with a different capacity is used.
2. The nozzle output has increased due to wear.

MC/2 operating unit

This high-pressure manual operating unit is used in configurations with piston or diaphragm pumps.

It consists of a pressure valve with a built-in pressure gauge.

To adjust the pressure, turn the black handle. To increase the pressure, turn the handle clockwise. To decrease pressure, turn it anti-clockwise.

The spray can be controlled from the tractor using the two remote levers.

Each lever controls one section valve. You can select one section, two sections or no sections open.



5 - Operation

Cleaning

General information

In order to be able to use your mistblower for many years, a maintenance programme needs to be followed. This programme should include a comprehensive cleaning procedure.



ATTENTION! Always read the individual sections. Carefully read the maintenance task instructions before starting. If any part of these instructions is unclear, for safety reasons, please contact your HARDI dealer for further information.



ATTENTION! A clean mistblower is a safe mistblower.
A clean mistblower is always ready for action.
Clean mistblowers are not damaged by pesticides and their solvents.

Steps to follow

1. Fully read the chemical product's label. Take note of any special instructions regarding protective clothing, deactivating agents, etc. Read the labels on the detergents and deactivating agents. If any cleaning procedure is specified, follow it accordingly.
2. Familiarise yourself with local legislation regarding the disposal of pesticides, mandatory decontamination methods, etc. Contact the appropriate department, e.g. Department of Agriculture.
3. Pesticide washings can usually be emptied out on a soakaway or retained at a washing location (See "Filling/washing location requirements"). This must be an area not used for crop growing. You must avoid seepage or runoff of residue into watercourses, wells, springs, pools, etc. The fluid remaining after rinsing the equipment cannot be disposed of down a sewer. It must be emptied into a suitable soakaway.
4. Cleaning starts with calibration. A properly calibrated mistblower ensures a minimal amount of fluid remaining.
5. It is good practice to clean the mistblower immediately after use, leaving it safe and ready for the next spray job. This prolongs the life of the parts.
6. At times, the spray liquid may need to be left in the tank for a short time e.g. overnight or until weather is suitable for spraying. Unauthorised persons or animals should not have access the mistblower under these circumstances.
7. If the product applied is corrosive, all metal parts of the machine before and after use should be coated with a suitable rust inhibitor.

Cleaning and maintaining the filters

Clean filters ensure:

1. Mistblower parts, such as the valves, diaphragms and operating units, are not blocked or damaged during use.
2. Nozzles are not blocked during spraying.
3. The pump has a long service life. A clogged suction filter will result in pump cavitation. The main filter that protects the mistblower parts is the suction filter. Check it regularly.



ATTENTION! It is strongly recommended to pump antifreeze liquid, Glycol "through the entire circuit, move all manifolds valves; let the pressure safety valve pop..
No matter if the machine is in a warm climate, it simply conserves all synthetic part in the circuit.

Cleaning the tank and liquid system

1. Dilute remaining spray liquid in the tank with at least 10 parts of water and spray the liquid out in the crop/ orchard just sprayed.
2. Select and use the appropriate protective clothing. Select detergent suitable for cleaning and suitable deactivating agents if necessary.
3. Rinse and clean mistblower and tractor externally. Use detergent if necessary.
4. Remove tank and suction filters and clean. Be careful not to damage the mesh. Replace suction filter top. Replace filters when the sprayer is completely clean.
5. With the pump running, rinse the inside of the tank. Don't forget the tank roof. Rinse and operate all components and any equipment that have been in contact with the chemical. Before opening the distribution valves and spraying the liquid out, decide whether this should be done in the field again or on the soakaway.
6. After spraying the liquid out, stop the pump and fill at least 1/5 of the tank with clean water. Note that some chemicals require the tank to be completely filled. Add appropriate detergent and/or deactivating agent, e.g. washing soda or Triple ammonia.
7. Start the pump and operate all controls enabling the liquid to come into contact with all the components. Leave the distribution valves until last. Some detergents and deactivating agents work best if left in the tank for a short period. Check the label.
8. Drain the tank and let the pump run dry. Rinse inside of the tank, again letting the pump run dry.
9. Stop the pump. If the pesticides used have a tendency to block nozzles and filters, remove and clean them immediately.
10. Replace all the filters and nozzles and store the mistblower. If, from previous experiences, it is noted that the solvents in the pesticide are particularly aggressive, store the sprayer with the tank lid open.



ATTENTION! It is advisable to increase the forward speed (double, if possible) and reduce the pressure to 1.5 bar (20 psi) when spraying diluted remaining liquid in the field just sprayed.



ATTENTION! If a cleaning procedure is given on the chemical label, follow it closely.



ATTENTION! If the sprayer is cleaned with a high pressure cleaner, lubrication of the entire machine is recommended.

Use of rinsing tank and rinsing nozzles (optional)

The incorporated rinsing tank can be used for two different purposes.



ATTENTION! If a cleaning procedure is given on the chemical label, follow it closely.

In-field diluting before cleaning

In-field diluting of remaining spray liquid residue in the spraying circuit, before cleaning the sprayer.

Rinsing the tank and liquid system

1. Empty the sprayer as much as possible. Close the Agitation Valve (no agitation) and spray till air comes out of all nozzles.
2. Turn suction valve towards "Rinsing tank" and pressure valve towards "Spraying".
3. Engage and set the pump at approximately 300 r.p.m.

5 - Operation

4. When 1/3 of the contents in the rinsing tank is used, turn suction valve towards "Main tank" and operate all valves on the pressure side of the system in the following order so that all hoses and components are rinsed:
 - I. Turn the pressure valve towards TurboFiller (if fitted) and open the TurboFiller suction valve.
 - II. Open TurboDeflector valve and close it again when clean water comes out of nozzles.
 - III. Close TurboFiller lid and squeeze the Chemical Container Cleaning grip to clean this device.
 - IV. Open TurboFiller lid again and make sure that TurboFiller is empty.
 - V. When empty, close the TurboFiller suction valve again.
 - VI. Turn the suction valve towards "Main tank" and the pressure valve towards "Spraying" and spray the liquid in the field just sprayed.

Cleaning of Main tank

5. Turn the suction valve towards "Rinsing tank" and the pressure valve towards "Internal Tank Rinsing". Remove the filling strainer to avoid any cleaning shadows behind it.
6. When another 1/6 of the contents in the rinsing tank is used, turn the suction valve towards "suction from Main tank".
7. Turn pressure valve towards "Spraying" and spray the liquid in the crop/orchard just sprayed.
8. Repeat point 6 - 8 one more time.



WARNING! When critical chemicals have been used, before spraying another crop/orchard sensitive to the chemical just used or a cleaning detergent is recommended, do an extra cleaning:

9. Fill the rinse tank again.
10. Fill the main tank with 500 l clean water.
11. Add the cleaning detergent to the main tank by using the TurboFiller. Follow instructions on the label of the cleaning agent.
12. Clean the whole system again.
13. To get the best cleaning effect the Self-Cleaning Filter and the Suction Filter sieves should be washed with clean water.
14. Rinse the sprayer with clean water afterwards.



ATTENTION! The rinsing nozzles cannot always guarantee a 100% cleaning of the tank. Always clean manually with a brush afterwards, especially if crops sensitive to the chemical just sprayed are to be sprayed afterwards!

Rinsing when main tank is not empty

Rinsing the pump, operating unit, spray lines, etc. in case of stop in spraying before main tank is empty (e.g. beginning rain etc.).

Cleaning of the liquid system:

1. Turn suction valve towards "Rinsing tank". (Keep pressure valve in "Spraying"-position).
2. Close AgitationValve (no agitation).
3. Engage the pump and spray the water from the rinsing tank in the field until all nozzle tubes/nozzles have been flushed with clean water.
4. Disengage pump again.

5 - Operation



ATTENTION! It is advisable to increase the forward speed (double, if possible) and reduce the pressure to 1.5 bar (20 psi) when spraying diluted remaining liquid in the field just sprayed.



ATTENTION! If the sprayer is cleaned with a high pressure cleaner, lubrication of the entire machine is recommended.

6 - Maintenance

Lubrication

General information


Keep all lubricants clean and stored in a cool, dry place to avoid contamination from dirt and condensed water. Keep all oil filling jugs, funnels and grease guns clean and clean the lubricating points once lubricated. Avoid skin contact with mineral oil products for long periods.

Always follow the guidelines on the recommended amounts. If the recommended amount is not given, lubricate until traces are visible. The pictograms on lubrication are as follows:

1. Lubricants to be used (See 'Recommended lubricants').
2. Operating hours before next lubrication.



ATTENTION! If the sprayer is cleaned with a high-pressure water cleaner, the whole machine should be lubricated.




Recommended lubricants



BALL BEARINGS

Universal Lithium grease, NLGI No. 2
SHELL RETINAX EP2
CASTROL LMX grease



SLIDE BEARINGS

Lithium grease enhanced with molybdenum or grafite disulphate
SHELL RETINAX HDM2
CASTROL MOLYMAX



OIL LUBRICATION


TOTAL Transmission TM SAE 80W/90
Castrol EPX 80W/90
SHELL Spirax 80W/90
Mobil Mobilube 80W/90




OIL LUBRICATION

SAE 30W
SAE 20W/50

Lubricating and greasing the mistblower



6 - Maintenance



Grease or oil all pivoting, telescoping and moveable parts on all boom and spout types every 100 hours.

It is a general illustration, functions such as Varia and others, might not be present on your machine.


Stop tractor engine while servicing the machine.

6 - Maintenance

Transmission shaft

The universal joints and bearings should be lubricated with grease. At points marked (A), this should be done after every 10 working hours, and the tubes and axles (B) every 50 hours.

Remember to lubricate the joints of the transmission shaft between pump and fan gearbox as well.



Tank transmission shaft

Loosen the two nuts on the PTO protection in ends, pumps and gear box.

Twist and pull back the protection.

Grease the yoke .

Put back both protections tighten nuts.



Diaphragm pump



Grease the pump every 50 working hours or once a month, through the grease nipple located at the crankshaft axle. The grease travel along the grooves in the crankshaft to reach the crankcase where it is distributed around bearings, conrods, etc.

Greasing is carried out in the same way on both pump models 363 and 463.



ATTENTION! Insufficient greasing of the pump could cause it to overheat and break the mobile parts inside.

Pump models 363 and 464 have external central grease nipples.



6 - Maintenance

Filters and fittings

Inspect the filters every 50 working hours. Apart from ensuring that they are clean, make sure that the mesh is in good condition. Otherwise, the efficiency of the filters will be reduced.

Whenever dismantling a filter or hose pipe, take care not to pinch the o-rings fitted to them. When replacing the pipe fitting, lubricate the o-ring with oil or grease so it seats in the groove.



ATTENTION! If the filter is not in good condition, it could cause numerous unnecessary interruptions during the working day, extending the working time required.



ATTENTION! Each time you remove a fitting to check the condition of its o-ring or for any other reason, remember to lubricate the O-ring with oil or grease to prevent it from being pinched or breaking when reassembling the fitting in its housing.




ATTENTION! Insufficient greasing of the pump could cause it to overheat and break the moving parts inside.

Fork drawbar

Keep the moving parts greased through the grease nipple to avoid wear and seizing up.


Also grease the contact faces of fork and drawbar.



Ring drawbar

Keep the moving parts greased through the grease nipple to avoid wear and seizing up.

Also grease the contact faces of hitch ring and drawbar clevis.




6 - Maintenance

Articulated drawbar


Keep the moving parts greased through the grease nipple to avoid wear and seizing up.

In the pivoting axle of the articulated drawbar a second grease nipple is to be greased.

Also grease the moving parts between pins and lower link balls.



The turnable drawbars, must be greased as per every 100 hours, through indicated grease nipples.



ATTENTION! The turn stop welded to the ball prevents the equipment from performing too tight turns that could cause it to break. Do not force turns beyond this point as this may damage the drawbar parts.




DANGER! Always stop the PTO when taking very tight turns, even when using a transmission shaft with wide-angle CV joint. Tight turns with the PTO on may cause the CV or the pump crankshaft to break and cause major vibrations in the gearbox. This may lead to damages of the fan or air kit.

Axles with brake

The hub is the part of the axle that must be greased. Remove hub cap (A) and grease the inside of the rotating head.

Where your machine is fitted with the axle with hydraulic brake, the moving part of the brake (B) must also be greased. Grease at least once a year.



Service and maintenance intervals

General information

The maintenance and replacement intervals of the elements listed as follows will depend on the conditions under which the mistblower will be used, and hence impossible to assess.



WARNING! If you do not feel confident in carrying out some of the maintenance jobs described below, then contact your HARDI dealer's workshop for assistance.

Every 10 working hours – Spray circuit

Fill the tank with clean water, activate all the functions and check for leaks using higher spray pressure than normal.

Check visually the cone of the nozzles to detect for imperfections.

Every 50 working hours – Transmission shaft, chassis, air pressure and diaphragm pump

Check the condition of the transmission shaft protection guard. Replace any damaged parts as required.

Re-tighten the bolts of the wheels and the areas under the greatest stress or torque.

Check/adjust tyre pressure.

Check/adjust pressure in pump pressure pulsation damper.

Grease the diaphragm pump.

Every 100 working hours – Drawbar

Grease the drawbar or ball of the mistblower.

Check that the pivoting axles are not blocked or deformed.

Grease and oil all moveable parts.

Every 250 working hours – Wheels, brakes, hoses and gearbox

Check and grease the hub and the wheel braking system.

Verify the hydraulic brake.

Check all the hoses in the circuit.

Check the gearbox support and re-tighten the bolts holding it in place.

Every 1000 working hours – Full service

Perform a full service on all the parts described previously.

Change the gearbox oil.

Dismantle and grease the transmission shaft and joints going through the main tank.

Dismantle the fan clutch and clean/lubricate.

6 - Maintenance

Regular maintenance


Every 10 working hours – Suction filter

To service the suction filter, proceed as follows:

1. Undo the nut (A) and open up the filter.
2. Remove the filter (B) from its housing.
3. Replace the O-rings (C) if necessary.

To put it back together:

4. Grease the O-rings.
5. Fit the filter inside its housing.
6. Grease the O-rings inside the cover of the filter
7. Put the cover back on and tighten it.



Every 10 hours of operation – Pressure filters

Remove the pressure filter, unscrew the filter housing to inspect and clean the filter. When you reassemble the filter, grease the o-ring.

There are different mesh sizes. See the section “Technical specifications- Filters and nozzles”.



Inspect daily the oil level on the gear box.

Vine sprayers, at the galls level indicator.

Orchard sprayers, at the glass indicator on the gear box.



Air sprayers with axial fan equipped with DUO or Jet deflector and or Turbine air sprayers (Vine sprayers) has an external level indicator, as the access the inspection glass on the gear box is hidden on those models. All other models, axial fan, needs to be inspected on the gearbox glass.



6 - Maintenance

Every 10 working hours – Nozzles

To clean or replace the nozzles, use a spanner to undo the nut (D).


Remove the nozzle and clean it with air, water or a toothbrush.



ATTENTION! Never use a piece of wire or a needle as this could cause irreparable damage to the nozzle.

If any of the nozzles leak when closing the spray section valve, the non-drip diaphragm should be replaced.

The nozzles should be replaced when their unit flow varies more than 10%. Worn or damaged nozzles may cause crop damages or insufficient results.



Every 1000 working hours - Gearbox oil change

Change the oil after the first 150 working hours then every 1000 working hours or once a year - which ever comes first.


Run the mistblower until the gearbox has reached normal operating temperature before draining the oil.



Clean the pump and area around dip stick, and drain plug before changing the oil

Fill with Fresh oil until the level reaches the level hole (B) Capacity: Approximately 1.25 litres.

- A. For Oil filling (SAE 90)
- B. Oil Level indicator




6 - Maintenance

Every 1000 working hours - Fan clutch inspection

Every 1000 working hours or once a year the fan clutch is dismantled for inspection, cleaning and lubrication.

1. Remove the fan clutch from the fan using the puller tool (Part No. 289659).
2. Remove the springs (A) and the two wings (B) using a mallet.
3. Polish the two axles (C) of the core with a fine emery cloth to remove dirt and rust.
4. Also polish the inside hole of the wing (D).
5. Check that the discharge hole in the ferodes (E) is not blocked.
6. Lubricate the axles of the wings and inside the core lightly with oil before re-assembling.
7. Check that the springs still work properly.
8. Re-assemble in reverse order.



WARNING! If the clutch is not maintained it may malfunction and cause severe damages to the fan unit!

Every 1000 working hours - Fan transmission shaft inspection

Every 1000 working hours or once a year - whichever comes first - the transmission shaft between pump and gearbox is dismantled for cleaning, inspection and lubrication.

1. Remove the protection cover between pump and main tank.
2. Detach the cardan joints from the pump and gearbox shafts.
3. Detach the suction and pressure hoses and the 4 bolts holding the pump. Lift the pump away.
4. Pull the transmission shaft out of the tunnel.
5. Separate the male and female part of the shaft.
6. Clean the profile tubes (inside and outside) thoroughly with a degreasing fluid (Alt. petrol, white spirit or similar) and wipe them dry.
7. Inspect the cardan joints for wear - replace journal crosses if necessary.
8. Grease the cardan universal journal crosses.
9. Grease the profile tubes and the splined shafts of the pump and gearbox.
10. Assemble again in reverse order, tighten bolts and ensure protection covers are in place.



WARNING! If the transmission shaft is not cleaned and lubricated as described it will not be able to extend or retract during operation when load is applied. This may overload the bearings on pump and gearbox or cause vibrations in the transmission and fan!

Occasional maintenance

Replacing the 321 valves and diaphragms

Diaphragms

Dismantle the crankcase (4). Now, the diaphragm (5) can be replaced. Grease the pump if the liquid has leaked to the inside. Make sure that the draining hole is not obstructed. Reassemble the pump again.

Torque settings for the 321 are:


Crankcase: 60 Nm / 44.4 lbft.

Crankshaft: 70 Nm / 51.8 lbft.

Diaphragm screws: 60 Nm / 44.4 lbft.



WARNING! Before assembling the covers, turn the shaft with the hand and make sure that the connecting rods are ascending and descending respectively. If not change the position of the connecting rods. The first connecting rod must be assembled towards the right-hand side.



SV operating unit

The SV operating unit open and close via a pilot line as in picture A, a small piston activated by the solenoid, opens up a small hole, hereinafter the liquid pressure opens up the larger diaphragm B in the valve, and allows the liquid to flow to the nozzles.

The pilot line can block due to sedimentation of chemicals.

Unscrew the 4 allen bolt, lift up the piston as in picture A, rinse out and reassemble.



6 - Maintenance

CB Section valve

The CB operating motor valve, is fitted with end stop, a micro switch.

It can be worn out, if that is the case; the electrical supply is not cut by the micro switch. Therefore the motor keep turning unlimited.

It will burn the fuse.

Pull out the clip as illustrated, lift gently up the gear motor; replace the micro switch as illustrated in the picture showing the gear motor end



Sealing in the operating unit.

Wear and tear parts in the on/off function of the valve, needs to be replace if the nozzle keeps on spraying weakly after closing a section or the main valve.



6 - Maintenance

Apply thread sealant on seat the and screw it on the end of by-pass hole up to beat. Use the socket wrench. Do not exceed with torque.

Apply the thread sealant on sleeve assembly, and tighten on valve body up to beat using the a wrench.

Tighten up to beat the stud B on the seat forcing lightly to obtain a tighten connection.


Insert spring and lock into sleeve

Apply some lubricant inside handle. Place sealant at the end of stud B thread and screw on handle C up to overlap the last notch on valve body.

Screw on and lock up to beat the nut holding the handle while tightening.



WARNING! to operate the gear motor unit 1, install 1.25A fuse on 12Vdc line



The mark on lock A and gear motor cam must be aligned as illustrated. These marks are referred to notch on gear motor crankcase. To obtain the correct position, connect the brown cable to + pole of battery and the blue one to - pole.


Lubricate the gear motor crankcase and O Rings. Insert the gear motor unit inside the valve body. The gear motor cap must beat on valve body.

Assembly the lock.

Assemble all accessories and connect wiring.



ATTENTION! Brown cable to + pole to obtain this position



6 - Maintenance

Cleaning the air kit



ATTENTION! Never access area or adjust deflector or any other part near the air kit, while tractor is started.



Cleaning of air kit.

To prevent unbalance that can cause dangers destructive vibrations with dangerous outcome for surroundings.

Inspect for dust and or dirt sedimentation in the air kit.

Hose out the air kit occasionally to prevent dust sedimentation to built up. If it built up, and drop of in uneven locations, it creates unbalance in the air kit, and destroys drive line and the air kit it self.

Rinse the fan blade and inner fan house wall and back end of the air kit. The axial air is designed with natural drain that will let the water out on left and right side.



Do not rinse with high pressure on sealing, as e.g. in the centrifugal clutch area, see separate chapter for clutch maintenance.


The turbine air kit is fitted with a drain plug, that must be removed when rinsing out the dust and other dirt sedimentation from the turbine.



Tank level indicator adjustment

The level indicator reading should be checked regularly. When the tank is empty, the float should lie on the stop pin, of the rod, and the O-ring on the indicator should be positioned at the top position line (A).

If any deviation is found, pull out the plug (B), loosen screws (C), and adjust the length of the cord.



Replacing the valves and 363 and 463 diaphragms

Model 363

The repair kit for the 363 diaphragm pump (valves, seals, diaphragms, etc.) is available under HARDI part No. 750342.

Valves

Remove crankcase cover before replacing the valves. Remember their direction in order to assemble them correctly afterwards!



ATTENTION! When you remove the crankcase covers, you will see that there are 2 valves that are slightly different from the rest. For correct operation, remember to fit them in the same position and location as before.

Diaphragms

Remove the diaphragm cover. The diaphragm can then be replaced. If the liquid has leaked to the inside of the crankcase, grease the pump thoroughly. Make sure that the drain hole at the bottom of the crankcase is not blocked. Reassemble the pump completely.



The torque wrench settings for the 363 and 463 pumps are the following:

Crankcase cover: 90 Nm

Diaphragm bolt: 90 Nm



ATTENTION! Before tightening the four screws on the crankcase cover, the diaphragms should be centered to ensure correct seating and sealing between the crankcase and the cover. Turn the crankshaft if necessary.



6 - Maintenance

Lubrication

General information

Always store lubricants clean, dry and cool - preferably at a constant temperature - to avoid contamination from dirt and condensed water. Keep oil filling jugs, hoppers and grease guns clean, and clean the lubricating points thoroughly before lubricating. Avoid skin contact with oil products for longer periods.


Always follow the quality and quantity recommendations. If no quantity is recommended, feed the lubricator until new grease becomes visible.

Pictograms in lubrication & oiling plans designate:




1. Lubricant to be used (see "Recommended lubricants" below).
2. Recommended intervals. Shown in hours or with a symbol for occasional maintenance.
3. Amount to be used. Only shown if an amount is specified.



ATTENTION! If the sprayer has been cleaned with a high pressure washer, lubrication of the entire machine is recommended.



Recommended lubricants

	What to Lubricate?	Lubricant Type	Factory Use	Recommended Alternatives
	BALL BEARINGS and PUMP	Lithium based grease Consistency NLGI grade 2 Viscosity (@40°C) > 460 cSt	SHELL Gadus S3 V550L 1 Hardi pump grease cartridge (400g): Item no. 28164600	MOBIL grease XHP 462 TOTAL Multis Complex SHD 460
	BOLTS	Anti-corrosive wax	PAVA PV 700	TECTYL 506 WD
	VALVES and SEALS (O-RINGS)	NSF 51, NSF 61 silicone compound	DOW CORNING MOLYKOTE 111 Compound	

Grease Gun Calibration

Before lubricating the sprayer, you must calibrate your grease gun to ensure that the correct amount of grease is applied to each lubrication point. The correct amount of grease applied will prolong the lifetime of the sprayer.


Calibration example

1. Insert the correct grease cartridge in your grease gun.
2. Apply grease onto a tissue or a piece of paper. Complete 10 full strokes of the grease gun.
3. Place the paper with grease on a scale.
4. If your grease pile weighs for example 10 grams (A), then 1 stroke equals 1 gram of grease.

When calibrated you can count how many strokes to complete, when lubricating the different grease points on the sprayer according to the specifications.

Alternative method

1. Count the strokes, until you have 10 grams of grease piled up on the scale (A).
2. Now you can figure out how many strokes to use for applying a certain amount of grease to a lubrication point.



Greasing the Pump

The pump is greased as follows:


1. Factory greased:
300 g grease into each lubrication point (A).
2. Normal operation:
MUST be greased every 50 hours with 30 g grease into each lubrication point (A).
3. After disassembling the pump (diaphragm renewal, etc.):
MUST be greased with 200 g grease into each lubrication point (A).



ATTENTION! In order to avoid excessive wear it is important to use a recommended lubricant! See "Recommended lubricants" on page 4.



ATTENTION! The pump MUST be stopped during greasing!



6 - Maintenance

Service and Maintenance Intervals

50 Hours Service - Greasing the Pump


When operating the pump, it **MUST** be greased every 50 hours with 30 gram grease into each lubrication point.



ATTENTION! In order to avoid excessive wear it is important to use a recommended lubricant! See "Recommended lubricants" on page 83.



ATTENTION! The pump **MUST** be stopped during greasing!



Occasional Maintenance

Lifting and Removing the Pump


When lifting and removing the pump, use a shackle fitted to the built-in lifting eye located between the heads (A).



WARNING! To avoid damages in case of a free-falling pump, use lifting gear and a steel shackle with at least 3.5 tonnes max. tensile strength.




NOTE! Pump weight is approximately 75 kg.



Pump Valves and Diaphragms Renewal

1. Lift off the plastic covers (C) with your hands (A) by pulling with the finger tips while pushing with the thumbs in the centre, as shown in (B).



6 - Maintenance

Valves

2. Loosen the 4 head bolts (1).
3. Remove the head (2).
4. Change the valves (3) - note their orientation, so that they are replaced correctly!



ATTENTION! It is recommended to use new gaskets (4), when changing or checking the valves.

Diaphragms



5. Loosen the diaphragm bolt (5).
6. Remove the diaphragm washer (6).
7. The diaphragm (7) may then be changed.
8. Check that the drain hole (8) at the bottom of the pump is not blocked.
9. Apply a small amount of pump grease on the underside of the diaphragms (between diaphragm and conrod washer).
10. Reassemble the pump with the following torque setting.
 - Diaphragm head bolts (1): 90 Nm.
 - Diaphragm bolt (5): 90 Nm.
11. Refit the plastic covers (C).



NOTE! The diaphragm bolt on 1000 r.p.m. pumps must be secured with locking compound.



ATTENTION! Before tightening the 4 bolts for the head (2), the diaphragm must be positioned between centre and top to ensure correct sealing between diaphragm pump housing and diaphragm cover. Turn the crank shaft if necessary.



Re-lubrication after assembly


After disassembling the pump (diaphragm renewal, etc.) the pump MUST be lubricated with 200 g grease into each lubrication point. Hardi pump grease cartridge (400g): Item no. 28164600

Overhaul Kit

Pump model: 364 and 464.

Diaphragm pump overhaul kit (valves, seals, diaphragms etc.) can be ordered. Detect the pump model - the overhaul kit can be ordered by your local dealer.

Model 364: Item no. 75585900. Model 464: Item no. 75586000.




6 - Maintenance

Adjusting the 3-way valve

The 3-way valve can be adjusted if it is too tight or too loose (liquid loss). It is correctly adjusted when the valve handle can be turned using one hand only.

To ease operation clean the mating faces between ball (B) and the seat (A) of the valve.

Grease the valve every time you dismantle it for cleaning. This will extend the service life of ball and seat.




Replacing the driveshaft protector guard

1. Remove the screw (A), cap (B) and grease nipple (C): Twist the cover a quarter of a turn and pull it back.
2. Remove the synthetic bearings and the protection guard.
3. Remove the inner bush from the protection guard.
4. Re-assemble in the reverse order, using new parts if necessary. Remember to assemble the chains again.
5. Grease the bearings.




ATTENTION! Only use original HARDI parts to repair the driveshaft.



Replacing the driveshaft crossheads

1. Remove the protection guard as described previously.
2. Remove the Segor rings.
3. Press the cross journals to one side (use a hammer and mandrel if necessary).
4. Remove the cross journal bearings and then remove the cross journal.
5. Remove the bearings from the new cross journal carefully and then install it. Before fitting the bearings again, check that the unit is assembled correctly. Protect the new bearings from dirt and dust.



6 - Maintenance

Annual maintenance of tank PTO

The PTO though the tank must be kept in good and well-greased shape, to secure it telescopes.

If it does not, it will provoke destructive pressure against the pump and gear box.

As well a non-telescoping PTO might provide destructive vibrations in the spray.

Unbolt the PTO from pump and gear box

Unbolt and Crain out the pump.

Pull put the PTO shaft

Pull the PTO apart in male and female part

Clean it well

Grease it

Grease Gearbox PTO tap and pump PTO tap-

Put back in the PTO shaft and bolt on the gear box tap.

Crain in the pump, bolt it to the chassis

Bolt on the PTO to the pump

Remember weekly PTO greasing / every 50 hours of the tank PTO



6 - Maintenance

Replacing the seal on the drain valve

If the drain valve leaks, the seal and the seat can be replaced as follows:


1. Make sure that the tank is empty and clean.
2. The valve must be closed and the lever loose.
3. Remove the U-clip A and pull the connection part B. Now the whole valve can be removed.
4. Check the condition and wear of the cord and the valve C, replace the seal D and reassemble.
5. Grease all o-rings F before assembling.
6. Fit the U-clip A again.



DANGER! Do not enter the tank – the parts can be replaced from outside the tank!



WARNING! Use a protective face mask when disassembling the drain valve!



Storing the mistblower at the end of the season

When the spraying season is over, you should devote some extra time on the machine before storing it. If any chemical residues are left on the mistblower for a long period, it can reduce the service life of the components. To keep the mistblower intact and protect the components, you should perform the tasks as part of an off-season storage programme.

1. Clean the mistblower completely inside and out, as described in 'Cleaning the mistblower'. Make sure that all the valves, hoses and auxiliary equipment have been washed with detergent and rinsed with clean water afterwards, to ensure that no traces of chemical products are left on the mistblower.
2. Replace the o-rings and repair any possible leaks.
3. Empty the mistblower completely and let the pump work for five minutes. Open all the valves to drain as much water as possible from the circuit.
4. Pour approximately 50 litres of anti-freeze mixture in the tank (1/3 anti-freeze and 2/3 water).
5. Start the pump and operate the controls of the 3-way valves, operating unit, etc. so that the anti-freeze is distributed throughout the entire circuit. Open the main ON/OFF valve and the distribution valves so that the anti-freeze is delivered through the nozzles also. The anti-freeze prevents the o-rings, seals, diaphragms, etc. from drying out.
6. Lubricate all the lubrication points according to the lubrication scheme. Disregard the normal lubrication intervals in this case.
7. When the mistblower is dry, remove the rust from any possible scratches or marks in the paint, and touch up the paintwork.
8. Remove the pressure gauge and store it a vertical position in a frost-free location.
9. Apply a thin layer of anti-corrosion oil (e.g. SHELL ENSIS FLUID, CASTROL RUSTILLO or similar) to all metal parts. Do not apply to hoses or rubber parts.
10. All the electric plugs and sockets must be kept in plastic bags to protect them from damp, dirt and rust.
11. Remove the control box from the tractor (if fitted), and store it in a clean, dry place (in-house).
12. To protect the mistblower against dust, it can be covered with a tarpaulin. Make sure that it is ventilated to prevent condensation.

6 - Maintenance

Preparing the machine for use after storage

After storage, the machine should be prepared for safely starting work at the beginning of the season. To start up the machine correctly, proceed as follows:

1. Remove the tarpaulin protecting the machine if there is one.
2. Fit the pressure gauge again. Replace the old Telfon tape.
3. Connect the equipment to the tractor, including electric wires and hydraulic cables.
4. Check the brake.
5. Empty the tank of any remaining anti-freeze.
6. Rinse out the entire fluid circuit with clean water.
7. Fill the tank with clean water and check all functions.

Operational problems

General information

In almost all breakdowns, the same factors always seem to be present:

1. Small cracks or air leaks in suction side reduce the pump's capacity or stop suction completely.
2. A blocked suction filter causes the pump not to suck properly.
3. Clogged pressure filters cause pressure to rise on the pressure gauge but to fall at the nozzles.
4. Foreign bodies in the valves can cause the valve to not close completely. This reduces the pump's performance.
5. Poorly re-assembled pumps, especially diaphragm housings, causes the pump to suck air and hence, reduces or decreases the pump suction.
6. Hydraulic components that are contaminated with dirt result in rapid wear to the hydraulic system.

Therefore ALWAYS check that:

1. Suction, pressure and nozzle filters are clean.
2. Hoses have no leaks or cracks, especially the suction hoses.
3. Gaskets and o-rings are in good condition.
4. Pressure gauge marks the correct indication. Correct dosage depends on its accuracy.
5. Operating unit is in good working order. Use clean water to check it.
6. Hydraulic components are maintained clean.

7 - Troubleshooting

Fluid circuit

FAULT	PROBABLE CAUSE	POSSIBLE SOLUTION
On activating, the system doesn't spray	Air in the suction line.	Check the suction filter o-ring. Check the suction tube and fittings. Check the assembly of the pump crankcase covers and diaphragms.
	Air in the system.	Prime the pump by filling the hose with water
	Suction or pressure filters blocked.	Clean the filters Check the suction fitting and make sure that it is not too close to the outlet on the tank floor.
Loss of pressure	Incorrect assembly	The safety valve's spring is damaged. The suction fitting is blocked The suction filter is clogged
	Pump valves clogged or worn	Check for obstructions and wear
	Defective pressure gauge	Check for dirt in the intake
Pressure jumps	Filters clogged	Clean the filters. Clean with clean water. If powdered product is being used, check that agitation is on.
	Worn nozzles	Check that the air flow does not exceed 10%.
	Tank suction clogged	Check the suction tube
	Air suction	Reduce revolutions in the PTO
Increase in pressure	Pressure filters blocked	Clean the filters
Foam formed	Air in the circuit	Check the o-rings, gaskets, hoses and suction fittings
	Excessive agitation.	Reduce revolutions in the PTO Check the voltage of the safety valve of the self-cleaning filter Make sure that there is return to the tank Use anti-foaming agent
Leak of pump liquid	Diaphragms damaged	Replace
The operating unit does not work	Fuse blown	Check the limit switches. Oil with lubricant if the limit switch does not make proper contact.
	Incorrect polarity	Control box: Red - pos (+) Black - neg (-). Solenoid valves: Brown - pos (+). Blue - neg. (-).
	The valves do not close correctly.	Check for obstructions in the valves Check the limit switches
	No power	Incorrect polarity. Brown is pos. (+), Blue is neg. (-) Check the electric board Check that the fuse box makes contact with the bracket.

7 - Troubleshooting

Blower unit

FAULT	PROBABLE CAUSE	POSSIBLE SOLUTION
Excessive noise or vibrations in the blower unit	The fan is incorrectly counterbalanced	Balance the fan again
	The nuts that hold the air kit are loose.	Tighten the nuts.
	The clutch pads are broken or worn.	Change the pads and the clutch springs or replace the clutch for a new one
Vibrations or noises in the gearbox	The gear is not properly engaged.	Move the gear lever to the correct position
	Worn gears	Replace the gears
	Oil level below minimum	Fill to the correct level and check for possible internal damage

7 - Troubleshooting

Electrical problems


Emergency function – Fluid circuit

In the event of power fault, the CB operating unit can be used manually. First disconnect the wire from the control box. Then manually turn the green throttle valve on each electric motor to open or close the valve.

The problem may result from a blown control box fuse.

8 - Technical specifications

Axial dimensions and weight



Neptun compact

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
600	2850-3150	1100-1550	1550	800	950	590	533	57
800	3050-3350	1100-1550	1550	1000	950	620	558	62
1000	3250-3550	1100-1550	1600	1000	950	675	608	67
1300	3250-3550	1100-1550	1600	1000	1200	695	618	77

Neptun Plus axial

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	1450-2100	1455	650-1250	1200	695	625	70
1500	3596-4339	1550-2100	1550	650-1410	1350	845	791	54
2000	3995-4738	1550-2100	1550	650-1550	1500	905	847	58
3000	4095-4838	1550-2100	1800	650-1550	1680	1020	930	90

8 - Technical specifications

Neptun Plus with Deflectors

	A	B	C	D	E	F	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	1450-2100	1455	650-1250	2300	1200	795	715	80
1500	3596-4339	1550-2100	1550	650-1410	2300	1350	940	880	60
2000	3995-4738	1550-2100	1550	650-1550	2400	1500	1025	959	66
3000	4095-4838	1550-2100	1800	650-1550	2630	1680	1140	1039	101

Zaturn Compact (mistake fro mprice list)

	A	B	C	D	E	F	P (Kg.)	P1 (Kg.)	P2 (Kg.)
600	2950-3450	1100-1550	1550	800	2300	950	670	610	60
800	3050-3550	1100-1550	1550	1000	2300	950	690	620	70
1000	3250-3550	1100-1550	1600	1000	2300	950	720	648	72
1300	3250-3550	1100-1550	1600	1000	2300	1200	740	658	82

Zaturn compact with deflector

	A	B	C	D	E	F	P (Kg.)	P1 (Kg.)	P2 (Kg.)
600	2950-3450	1100-1550	1550	800	2300	950	670	610	60
800	3050-3550	1100-1550	1550	1000	2300	950	690	620	70
1000	3250-3550	1100-1550	1600	1000	2300	950	720	648	72
1300	3250-3550	1100-1550	1600	1000	2300	1200	740	658	82

Zaturn Plus AG

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	1450-2100	1455	650-1250	1200	695	625	70
1500	3596-4339	1550-2100	1550	650-1410	1350	845	791	54
2000	3995-4738	1550-2100	1550	650-1550	1500	905	847	58
3000	4095-4838	1550-2100	1800	650-1550	1680	1020	930	90

Zaturn plus AG with deflectors

	A	B	C	D	E	F	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	1450-2100	1455	650-1250	2300	1200	795	715	80
1500	3596-4339	1550-2100	1550	650-1410	2300	1350	940	880	60
2000	3995-4738	1550-2100	1550	650-1550	2400	1500	1025	959	66
3000	4095-4838	1550-2100	1800	650-1550	2630	1680	1140	1039	101

Jupiter SF

A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)	P2 (Kg.)
1500	3596-4339	1550-2100	1550	650-1410	1350	845	791	54
2000	3995-4738	1550-2100	1550	650-1550	1500	905	847	58
3000	4095-4838	1550-2100	1800	650-1550	1680	1020	930	90

8 - Technical specifications

Jupiter SF with deflector


	A	B	C	D	E	F	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1500	3596-4339	1550-2100	1550	650-1410	2300	1350	940	880	60
2000	3995-4738	1550-2100	1550	650-1550	2400	1500	1025	959	66
3000	4095-4838	1550-2100	1800	650-1550	2630	1680	1140	1039	101

Zaturn plus AG with deflector

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)	P2 (Kg.)
1000	3386-3745	1450-2100	1455	650-1250	1200	695	625	70	60
1500	3596-4339	1550-2100	1550	650-1410	1350	845	791	54	70
2000	3995-4738	1550-2100	1550	650-1550	1500	905	847	58	72
000	4095-4838	1550-2100	1800	650-1550	1680	1020	930	90	82

8 - Technical specifications

Turbines dimensions and weight



8 - Technical specifications

Zaturn Compact Liner

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
600	2850-3150	1100-1550	1550	800	950	825	750	75
800	3050-3350	1100-1550	1550	1000	950	855	770	85
1000	3250-3550	1100-1550	1600	1000	950	915	813	102
1300	3250-3550	1100-1550	1600	1200	1200	940	828	112

Zaturn Plus Atlas

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	2300	2900	920 - 1860	1200	1150	987	163
1500	3596-4339	2300	2900	920 - 1860	1350	1300	1177	123
2000	3995-4740	2300	2900	920 - 1860	1500	1470	1420	50
3000	4095-4840	2300	2900	920 - 1860	1680	1475	1321	154

Zaturn Plus Boxer

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	2300	2900	920 - 1860	1200	1150	987	163
1500	3596-4339	2300	2900	920 - 1860	1350	1300	1177	123
2000	3995-4740	2300	2900	920 - 1860	1500	1470	1420	50
3000	4095-4840	2300	2900	920 - 1860	1680	1475	1321	154

Zaturn Plus Cronos

	A	B	C	D	E	P (Kg.)	P1 (Kg.)	P2 (Kg.)
1000	3386-3745	2300	2900	1170 - 2070	1200	1150	987	163
1500	3596-4339	2300	2900	1170 - 2070	1350	1300	1177	123
2000	3995-4740	2300	2900	1170 - 2070	1500	1470	1420	50
3000	4095-4840	2300	2900	1170 - 2070	1680	1475	1321	154

8 - Technical specifications

Conversion factors (SI to Imperial)

All units used in this instruction book are SI. In some cases, imperial units are used. Use these factors to convert between SI and Imperial units:

	SI unit	Imperial unit	Factor
Weight	kg	lb	x 2.205
Surface area	ha	acres	x 2.471
Length	cm	in	x 0.394
	m	ft	x 3.281
	m	yd	x 1.094
	km	mile	x 0.621
Speed	km/h	mile/h	x 0.621
	km/h	m/s	x 0.277
Volume/Surface area	l/ha	gal/acre	x 0.089
Volume	ml	fl. oz	x 0.0352
Torque	l	Imp. pt.	x 0.568
	l	gal	x 0.22
Pressure	bar	lb./inv (p.s.i.)	x 14.504
Temperature	°C	°F	(°C x 1.8) + 32
Power	kW	hp	x 1.341
Torque power	Nm	lb.ft.	x 0.74

8 - Technical specifications

Specifications

Pump model 363/7

HARDI		HARDI INTERNATIONAL A/S TAASTRUP DENMARK	
Type	363/7	r/min.	max. 700
No.			
r/min.	l/min.	bar	kW
540	140	0	1.6
540	127	10	3.4
		max.20	

Pump model 321/10

HARDI		HARDI INTERNATIONAL A/S TAASTRUP DENMARK	
Type	321/10	r/min.	max. 700
No.			
r/min.	l/min.	bar	kW
540	70	0	0.6
540	62	10	1.2
		max.20	

Filters and nozzles

Filter mesh width

30 mesh: 0.58 mm

50 mesh: 0.30 mm

80 mesh: 0.18 mm

100 mesh: 0.15 mm

Temperature and pressure range

Working temperature range: 2° – 40° C. (36°F – 104°F)

Pressure that activates the safety valve: 20 bar in HLC and 40 bar in HPC

Maximum pressure in the pressure valve: 20 bar in HLC and 40 bar in HPC

Maximum pressure in the suction valve: 7 bar

8 - Technical specifications

Materials and recycling

Disposing of the mistblower

When the mistblower has reached the end of its useful working life, it must be thoroughly cleaned. The tank, hoses and synthetic fittings can be incinerated in an authorised disposal depot. The metal parts can be scrapped. Always comply with existing local regulations.

Materials used:

Tank: MDPE

Hoses: EPDM

Valves: mainly PA+FG.

Fittings: PA+FG.

A

AB750 19
AB820 19
AB920 19
Adjustment of hydraulic fold 52
Adjustment of out spray device 53
Adjustment of upright 53
AG820 19
AG920 19
Agitator 16
Air flow for axial air kits 21
Air kit 95
ATLAS 29
ATLAS AGILE 48
ATLAS SOLID FIX 48
ATLAS SOLID FIX GV 48
ATLAS START 48

B

Before starting up for the first time 35
Blinds 58
BOXER 30
BOXER SOLID HORIZONTAL 49
BOXER SOLID VERTICAL FIX 49
BOXER START 49
Break away clutch 32, 52

C

Calibration 56
Cannon 68
CANNON 68
Cannons 56
CB/2 40
CB operating 66
CB operating unit 66
CB Section valve 93
Centrifugal Blower Units 24
Cleaning 79
Clutch 91
Clutch (All blower types) 26
Control 68
CRONOS 31
CRONOS BOOM 50
CRONOS GV 51

D

DB 3610 41
DB 3620 42
Deflectors 22, 44
Diaphragm pump 43, 85
Diaphragms 96
Drain valve 61
Driveshaft 38, 102
DUO P 46
DUOT 46

E

EF820 19
EF920 19
Electrical connections 40

Every 10 88
Every 10 hours 89
Every 50 88
Every 100 88
Every 250 88
Every 1000 88

F

FB 3610 41, 66
FB 3620 42
Filling 59
Filters 79, 108
FIX 47
Foam formed 108

G

Gearbox 23
Gear motor crankcase 94
Grease or oil 84
Greasing the Pump 98

H

HB 3610 41, 67
HB 3620 42
HC 3100 control 69
Hours 99
Hydraulic 107
Hydraulic adjustment 55
Hydraulic control boxes 67
Hydraulic pressure 39
Hydropneumatic spray system 33

I

IAG820 19
IAG920 19
Identification plate 11
IRIS system 34

J

JET 46
Job boxes 41, 42
Joystick S selector 67

L

LINER 28
Loss of pressure 108
Lubricants 83

M

Manifold system 14, 61

N

Noise 109

O

Oil level 89
Operating unit 107, 108
Operating Unit 78

P

P540 24
P540D 24

Pneumatic spray system 33
Power BOX 41, 42
Power supply 64
Pressure damper 43
Pressure gauge 107
Pressure jumps 108
Pressure manifold 16
PTO 103
Pulsation dampers 16

R

Rate controller DB 3610 41
Rate controller DB 3620 42
RIDER 31, 51
Rinsing nozzle 60
Rinsing tank 60
r.p.m. 20

S

Safety information 57
Safety valve 16
SB 3002 or SB 3004 65
SB 3012 or SB 3014 etc 65, 66
Selecting the gear 57
Serial number 11
SF65 19
SF85 19
SOLID 31, 50
Spray circuit 14
START 47
Suck properly 107
Suction 107, 108
Suction filter 15, 43
SV operating unit 65, 92

T

Transmission shaft 85
Transport bracket 53
TurboFiller 18, 63

V

Valves 96
VARIA 31, 51
Vegetation sensor 69
Vibrations 109

W

Way valve 102

X

XF90 19

Spart parts

For updated information on spare parts, visit www.agroparts.com
Here you can access information on all spare parts when you register for free.



ILEMO HARDI S.A.U.

Poligono Industrial El Segre 712-713 25080 Lleida - SPAIN

