

Enviromist Industries

REPLACEMENT OF G0001 SOLENOID WITH BI044 SOLENOID

- Disconnect and remove the G0001 but retain the blue fittings
- remove the existing solenoid bracket
- install new bracket
- **NOTE:** position "2" is the fluid in connection, position "1" is the fluid out side
- carefully remove base of BI044 solenoid (ensure that the plunger does not fall out) and position into the bracket in correct direction and re-connect the base
- connect 6mm tubing and fittings to BI044 – **NOTE:** may need to pull on the 6mm black tubing to get enough loose tubing.
- the red manual over-ride switch must be in line with the in-out for automatic operation
- re-connect wiring – **NOTE:** solenoid will work either way the wires are connected to the connection block